Instruction Manual

Please return to librarian:
Org. B-8729 MS 47 - 24
Manual # 1-A

MODEL 803B/AS

AC/DC

DIFFERENTIAL VOLTMETER

FLUKE
ELECTRONICS FOR INDUSTRY
INSTRUMENTS / COMPONENTS

JOHN FLUKE MFG. CO. INC.
P. O. Box 7428 Seattle 33, Washington

October 20, 1962

PLEASE RETURN TO LIBRARIAN
ORG. 6-7744 M.S. 27-14
manual # 3

MODEL 803B/AG

AC/DC
DIFFERENTIAL VOLTMETER

803B _____

803BR _____

803B/AG _____

803BR/AG _____

Copyright, John Fluke Mfg. Co., 1968

ADDENDUM

FLUKE MODELS

801B, 803B, 803D, 821A, 823A, and 825

The DC Differential Voltmeter Calibration procedure is ammended to employ the Fluke Model 332A DC Voltage Calibrator in lieu of the several instruments listed in section IV of the manual.

Procedures included in the manual call for the use of an Eppley standard cell, a galvonometer, two silver contact push-button switches, two resistors, a precision voltage divider and a power supply. The procedure is complex, requiring four expensive standards, and introduces error possibilities if considerable care is not exercised in assembling the set-up.

The Fluke Model 332A DC Voltage Calibrator provides, in one instrument, a reliable 0.003% accuracy over the entire range of DC input of the test instrument.

Generally, operation of the Model 332A DC Voltage Calibrator involves simply connecting the input of the instrument under test to the Model 332A output and dialing the desired voltage level on the Model 332A. As an example, consider calibration of the Model 803B on its 50 volt range.

a. Set the VOLTAGE RANGE dials of the Model 332A to 50 volts.

b. Connect the Model 803B INPUT to the Model 332A OUTPUT.

c. Set the Model 803B as follows:

RANGE	50
NULL	0.01
voltage readout dials	49.99<u>10</u>

d. Set the POWER switch of the Model 332A to STANDBY/RESET and then to ON.

e. Null the Model 803B by adjusting 50 V DC ADJ control R323.

For more detailed operation procedures consult the instruction manual for the Model 332A DC Voltage Calibrator and the manual for the instrument under test.

Digitized by the Internet Archive
in 2025

https://archive.org/details/manualsplus_07978

TABLE OF CONTENTS

Section	Title	Page
I	INTRODUCTION AND SPECIFICATIONS	1-1
	1-1. Introduction	1-1
	1-2. Damage in Shipment	1-1
	1-3. Specifications	1-1
II	OPERATING INSTRUCTIONS	2-1
	2-1. Controls, Terminals, and Indicators	2-1
	2-2. Zeroing Instructions	2-3
	2-3. Preliminary Operation	2-3
	2-4. Operation as a DC Differential Voltmeter	2-3
	2-5. Operation as an AC Differential Voltmeter	2-3
	2-6. Operation as a Conventional VTVM	2-4
	2-7. Measurement of Voltage Excursions about a Nominal Value	2-4
	2-8. Use of 803B with a Recorder	2-5
	2-9. Measurement of High Resistances	2-6
	2-10. Notes on Measuring AC or DC Voltages	2-6
	2-11. Notes on Measuring DC Voltages	2-7
	2-12. Notes on Measuring AC Voltages	2-7
III	THEORY OF OPERATION	3-1
	3-1. General	3-1
	3-2. DC Attenuator	3-2
	3-3. Null Detector	3-2
	3-4. 500 VDC Reference Power Supply	3-3
	3-5. Kelvin-Varley Divider	3-3
	3-6. AC to DC Converter	3-4
	3-7. AC - DC Polarity Switch	3-5
	3-8. Null Detector Power Supply	3-5
IV	MAINTENANCE	4-1
	4-1. General	4-1
	4-2. Preventive Maintenance	4-1
	4-3. Troubleshooting	4-1
	4-4 Calibration	4-4
V	LIST OF REPLACEABLE PARTS	5-1
VI	ACCESSORIES	6-1
	6-1. Precision Voltage Dividers	6-1
	6-2. Potentiometric Recorder	6-2
	WARRANTY	
	CIRCUIT DIAGRAM	

LIST OF ILLUSTRATIONS

Figure	Title	Page
Frontispiece	803B Precision AC/DC Differential Voltmeter	iv
2-1	Controls, Terminals, and Indicators (sheet 1 of 2)	2-1
2-1	Controls, Terminals, and Indicators (sheet 2 of 2)	2-2
2-2	Recommended Null Settings	2-3
2-3	VTVM Ranges	2-4
2-4	Full Scale AC Deflections	2-5
2-5	Recorder Recommended Connection Diagram	2-5
2-6	Percent Error Due to Harmonic Distortion	2-7
2-7	Signal Voltage with Converter Noise	2-8
3-1	803B AC/DC Differential Voltmeter Block Diagram	3-1
3-2	DC Function of AC-DC Polarity Switch	3-4
4-1	Troubleshooting (sheet 1 of 2)	4-2
4-1	Troubleshooting (sheet 2 of 2)	4-3
4-2	Calibration Equipment	4-4
4-3	Adjustment Locations	4-5
4-4	Tube Voltage Chart	4-5
4-5	DC Differential Voltmeter Calibration Set-up	4-7
4-6	AC to DC Converter Calibration Set-up	4-7
5-1	Final Assembly	5-3
5-2	Front Panel Assembly (sheet 1 of 2)	5-5
5-2	Front Panel Assembly (sheet 2 of 2)	5-6
5-3	Reference Board PCB Assembly	5-8
5-4	Null Detector Chassis Assembly	5-11
5-5	Range Resistor PCB Assembly	5-13
5-6	Kelvin-Varley Resistor PCB Assembly	5-14
5-7	Converter/AC Range Switch Assembly (sheet 1 of 2)	5-18
5-7	Converter/AC Range Switch Assembly (sheet 2 of 2)	5-19

MODEL 803B and 803B/AG



MODEL 803BR and 803BR/AG

SECTION I

INTRODUCTION AND SPECIFICATIONS

1-1. INTRODUCTION

a. This instruction manual is for use with the 803B series AC/DC Differential Voltmeters. These are available in either a cabinet model or a standard 19 inch rack model, and with either a standard cell or a Zener diode as the reference element. Model designations are: 803B (cabinet model, standard cell); 803BR (rack model, standard cell); 803B/AG (cabinet model, Zener diode); and 803BR/AG (rack model, Zener diode).

b. The high accuracy, portability, and compactness of the 803B make this instrument ideal for the precise measurement of almost any AC or DC voltage. Ease of operation, inherent protection from accidental overload, and high reliability contribute to the outstanding performance that assures suitability for both production line testing and precision laboratory measurements. This instrument is capable of being used as a vacuum voltmeter, as a precision potentiometer, and as a megohmmeter for measurement of high resistance. It can also be used to measure the excursions of a voltage about some nominal value. One feature that should be emphasized is that no current is drawn from the unknown source for DC measurements when balance is attained. Thus the determination of the unknown DC potential is independent of its source resistance. The 803B is basically used for measurements of DC voltages from 0 to 500 volts and AC voltages from 0.001 to 500 volts. However, high accuracy measurements to 30,000 volts DC are possible with precision voltage dividers especially designed for use with the Fluke Model 800 Series Differential Voltmeters. As additional features, this instrument contains a polarity switch for equal convenience in measuring positive or negative DC voltages and an adjustable recorder output which makes the 803B particularly useful for monitoring the stability of almost any AC or DC voltage. Furthermore, the 803B meter has taut-band suspension which eliminates problems due to meter stickiness.

c. When used as a DC Differential Voltmeter, the 803B operates on the potentiometric principal. An unknown voltage is measured by comparing it to a known adjustable reference voltage with the aid of a null detector. An accurate standard for measurements is obtained by setting the reference supply with a standard cell for the 803B and 803BR and with a Zener power supply for the 803B/AG and 803BR/AG. The known adjustable reference voltage is provided by a 500 volt DC power supply and five Kelvin-Varley decade resistor strings that are set accurately by five voltage readout dials. In this way, the 500 volts can be precisely divided into increments as small as 10 microvolts. The unknown voltage is then simply read from the voltage dials.

When used as an AC Differential Voltmeter, the 803B operates essentially the same as for DC differential measurements. The AC input voltage is converted to a DC voltage and this DC voltage is measured by comparing it to a known adjustable reference voltage. In the highest null sensitivity range, potential differences between the unknown and the reference voltage of only 0.01 volts for DC and 0.001 volts for AC will cause full scale meter deflection.

d. The instrument is normally supplied ready for use on 115 volts. Upon request, instruments are supplied for 230 volts operation. If it becomes desirable to convert from one mode of operation to the other, refer to the instruction decal on the back of cabinet models or on the cover in rack models.

1-2. DAMAGE IN SHIPMENT

Immediately upon receipt, thoroughly inspect for any damage that may have occurred in transit. If any damage is noted, follow the instructions outlined on the warranty page at the back of this manual.

1-3. SPECIFICATIONS

AS A PRECISION POTENTIOMETER

DC ACCURACY:

±0.05% of input voltage from 0.1 to 500 VDC
±(0.05% +50 uv) below 0.1 VDC

AC ACCURACY:

Input Voltage		0.5 to 500	0.001 to 0.5
Basic AC Accuracy from 20 cps to 10 kc		±0.2%	±(0.2% + 25 uv)
Low Frequency AC Accuracy	from 10 cps to 20 cps	±0.5%	±(0.5% + 25 uv)
	from 5 cps to 10 cps	±3%	±(3% + 25 uv)

RANGE:

For DC Measurements

Input Voltage Range	Recommended Null Range*	Input Resistance Per volt of input voltage	
		At Null	1% of Full Scale Off Null
50-500	10-0-10	Infinite	100 Meg
	1-0-1	Infinite	1,000 Meg
5-50	1-0-1	Infinite	1,000 Meg
	0.1-0-0.1	Infinite	10,000 Meg
0.5-5	0.1-0-0.1	Infinite	10,000 Meg
	0.01-0-0.01	Infinite	10,000 Meg
0-0.5	0.1-0-0.1	Infinite	10,000 Meg
	0.01-0-0.01	Infinite	10,000 Meg

*Any null range may be used with any input voltage range; recommended ranges are those most useful.

For AC Measurements

Input Voltage Range	Recommended Null Range	Input Impedance
50-500	100-0-100	1 Meg, 35 uuf
	10-0-10	1 Meg, 35 uuf
	1-0-1	1 Meg, 35 uuf
5-50	10-0-10	1 Meg, 35 uuf
	1-0-1	1 Meg, 35 uuf
	0.1-0-0.1	1 Meg, 35 uuf
0.5-5	1-0-1	1 Meg, 50 uuf
	0.1-0-0.1	1 Meg, 50 uuf
	0.01-0-0.01	1 Meg, 50 uuf
0.001-0.5	0.1-0-0.1	1 Meg, 50 uuf
	0.01-0-0.01	1 Meg, 50 uuf
	0.001-0-0.001	1 Meg, 50 uuf

RESOLUTION:

Voltage Readout Dial Resolution

Range Setting	Null Setting	Resolution
500	any	10 mv
50	any	1 mv
5	any	0.1 mv
0.5	any	0.01 mv

Meter Resolution
(1/4 of a small scale meter division)

Polarity Setting	Range Setting	Null Setting	Resolution
DC	any	10	50 mv
DC	any	1	5 mv
DC	any	0.1	0.5 mv
DC	any	0.01	0.05 mv
AC	500	1	500 mv
AC	500	0.1	50 mv
AC	50	1	50 mv
AC	500	0.01	5 mv
AC	50	0.1	5 mv
AC	5	1	5 mv
AC	50	0.01	0.5 mv
AC	5	0.1	0.5 mv
AC	0.5	1	0.5 mv
AC	5	0.01	0.05 mv
AC	0.5	0.1	0.05 mv
AC	0.5	0.01	0.005 mv

AS A VACUUM TUBE VOLTMETER

ACCURACY: 3% on all ranges

RANGE:

	Voltage Ranges	Input Impedance
DC:	500-0-500	50 Meg
	50-0-50	50 Meg
	5-0-5	50 Meg
	0.5-0-0.5	50 Meg
	10-0-10*	10 Meg
	1-0-1*	10 Meg
	0.1-0-0.1*	10 Meg
	0.01-0-0.01*	1 Meg
AC:	0-500	1 Meg, 35 uuf
	0-50	1 Meg, 35 uuf
	0-5	1 Meg, 50 uuf
	0-0.5	1 Meg, 50 uuf
	0-100**	1 Meg, 35 uuf
	0-10**	1 Meg, 35 uuf
	0-1**	1 Meg, 35 uuf
	0-0.1**	1 Meg, 35 uuf
	0-0.01**	1 Meg, 50 uuf
	0-0.001**	1 Meg, 50 uuf

*These ranges are obtained by using Null ranges with all five voltage readout dials set to 0.

**These ranges are obtained by the proper setting of the range and null switches with all five voltage readout dials set to 0.

GENERAL SPECIFICATIONS

REGULATION AND STABILITY OF 500 VOLT SUPPLY:

±0.0025% for a ±10% line change
±0.005% per hour after 30 min. warmup

STABILITY OF METER ZERO:

±0.5% of full scale for a 10% change in line voltage from a line frequency of 50 to 120 cps and ±1% of full scale for a 10% change in line voltage from a line frequency of 120 to 440 cps.

OPERATING TEMPERATURE RANGE:

Within DC specifications from 40°F to 105°F: Derate accuracy at 0.001% per °F outside these limits to 35°F and 110°F for standard cell models (803B and 803BR) or to 0°F and 125°F for Zener diode reference models (803B/AG and 803BR/AG). Below 0°F the Zener diode reference models operate with an accuracy of ±0.09% derated at 0.002%/°F to -25°F.

Within AC specifications from 55°F to 95°F: Derate accuracy at 0.005% per °F outside these limits to 35°F and 110°F for standard cell models (803B and 803BR) or to 0°F and 125°F for Zener diode reference models (803B/AG and 803BR/AG). Below 0°F the Zener diode reference models operate with an accuracy of 0.3% derated at 0.005%/°F to -25°F.

RELATIVE HUMIDITY:

Within specifications from 0 to 80% relative humidity.

SHOCK AND VIBRATION:

Meets requirements of MIL-T-945A

INPUT POWER:

115/230 volts AC (±10%), 50-440 cps, 75 watts. (Note: Models 803B and 803B/AG serial numbers 123 to 2616 and Models 803BR and 803BR/AG serial numbers 123 to 851 were manufactured to operate on line power frequencies from 50 to 70 cps.)

DIMENSIONS:

Cabinet Model-13" high, 9-3/4" wide, 16" deep.
Rack Model-7" high, 19" wide, 15-1/2" deep.

WEIGHT:

Cabinet Model-27-1/2 lbs.
Rack Model-25 lbs.

SECTION II

OPERATING INSTRUCTIONS

2-1. CONTROLS, TERMINALS, AND INDICATORS

The location, circuit symbol, and a functional description of external controls, terminals, and indicators on the 803B Precision AC/DC Differential Voltmeter may be found in figure 2-1.

CONTROLS TERMINALS AND INDICATORS	LOCATION	CIRCUIT SYMBOL	FUNCTIONAL DESCRIPTION
Input terminals	Front panel	J1, J3	Provided for connecting AC or DC voltage to be measured.
Chassis ground terminal	Front panel	J2	Provided for grounding purposes. A 0.47 uf capacitor is connected from the lower input binding post to the chassis ground post. The upper input post should never be connected to the chassis ground post. Since the instrument is equipped with a three-wire line cord with the third wire fastened to the chassis, the external circuit should be checked for conflicts in grounding before connecting lower input binding post (middle post) to the chassis post.
Power toggle switch	Front panel	S1	Applies AC line voltage to the primary circuit of the power transformer.
OPERATE-CALIBRATE switch	Front panel	S4	Remains in the OPERATE position at all times except when it is necessary to calibrate the internal 500 volt DC reference supply. When held in the CALIBRATE position, a representative sample of the reference voltage is compared to the voltage of an internal standard cell, or Zener reference diode for the /AG models, and any difference is indicated on the meter.
CALIBRATE control	Front panel	R2	Varies the output of the 500 volt DC reference supply. When the OPERATE-CALIBRATE switch is held in the CALIBRATE position, the reference supply is accurately set by adjusting the CALIBRATE control for zero meter deflection.
RANGE switch	Front panel	S2	Selects desired voltage range. Full scale voltage ranges of 500, 50, 5, and 0.5 volts are available. It also indicates the AC NULL MULT for each range position.

Figure 2-1. CONTROLS, TERMINALS, AND INDICATORS (sheet 1 of 2)

CONTROLS TERMINALS AND INDICATORS	LOCATION	CIRCUIT SYMBOL	FUNCTIONAL DESCRIPTION
NULL switch	Front panel	S3	Set to VTVM for determining the approximate value of unknown voltage prior to differential measurements. Four null switch ranges of 10, 1, 0.1, and 0.01 volts are used for differential measurements. For the DC mode, the null ranges represent full scale differences between the unknown voltage and the amount of precision internal reference voltage that is set on the voltage readout dials. For the AC mode, the null range used times the applicable AC Null Multiplier, indicated by the range switch, represents the full scale difference between the unknown voltage and the amount set on the voltage dials.
A, B, C, D, and E voltage readout dials	Front panel	S6, S7, S8, S9, S10	Provide an in-line readout of the amount of internal reference voltage necessary to null the unknown voltage.
Decimal lights	Front panel	DS1, DS2, DS3, DS4	Serve as decimal points for the voltage readout dials. A different light illuminates for each position of the RANGE switch.
AC - DC polarity switch	Front panel	S5	Selects the AC, + DC, or - DC mode of operation. With this switch in the positive position, the polarity of the upper input binding post is positive with respect to the lower input binding post (middle post).
Output terminals	Rear panel	J4, J5	Provided for attaching a recorder to monitor voltage excursions.
Output level control	Rear panel	R1	Varies the output level of the output binding post from 0 to approximately 20 millivolts full scale deflection.
Meter	Front panel	M1	Indicates approximate voltage when 803B is in VTVM mode and difference between unknown and internal reference voltage when 803B is in differential mode. The upper scale, 500-0-500, is used when the NULL switch is set to VTVM. At all other times, the lower scale, 1-0-1, is used.
Mechanical zero control	Meter case	None	Sets meter to zero mechanically. This adjustment should be used only after instrument has been turned off for at least three minutes or when the internal meter terminals have been shorted.
Fuse	Rear panel of cabinet models, front panel of rack models.	F1	Fuse holder protrudes from instrument to provide easy access to the fuse. The fuse is a 1.5 ampere slow blowing type for 115 volt operation and a 0.75 ampere slow blowing type for 230 volt operation.

Figure 2-1. CONTROLS, TERMINALS, AND INDICATORS (sheet 2 of 2)

2-2. ZEROING INSTRUCTIONS

From time to time, it may be necessary to adjust the internal meter zero control. This will normally be done at somewhat more frequent intervals than complete instrument calibration. It may also be necessary to adjust the internal meter zero control when the instrument is operated on a different line frequency than that at which it was originally zeroed. Proceed as follows:

a. Mechanically zero the meter with the adjustment screw on the front of the meter case. If the instrument is in the case, it must be shut off for at least three minutes prior to this adjustment. If out of case, another method would be to short out the internal meter terminals prior to zeroing.

b. Set power switch to ON and allow a 20 minute warm-up period.

c. Set RANGE switch to 5 or 0.5 volts, voltage readout dials to zero, and NULL switch to 0.01 volts.

d. Adjust R227, null detector ZERO ADJ, for zero meter deflection. This control may be reached through the ventilation holes in the cabinet model (see figure 4-3). In the rack model, an identified access hole is provided on the rear panel.

2-3. PRELIMINARY OPERATION

The following procedure prepares the voltmeter for operation.

a. Connect power plug to a 115 volt AC power source. If instrument has been wired for 230 volt operation, connect to 230 volts AC.

NOTE

The round pin on polarized three-prong plug connects instrument case to power system ground. Use a three-to-two pin adapter when connecting to a two-contact receptacle. For personnel safety, connect short lead to a suitable ground.

b. Set controls on 803B voltmeter as follows:

RANGE	500 volts
NULL	VTVM
AC-DC polarity	+ (positive)
all voltage readout dials	0 (zero)
power	ON

c. After a warmup period of at least ten minutes, advance OPERATE-CALIBRATE switch against spring tension to CALIBRATE, and adjust internal 500 volt DC reference supply with CALIBRATE control for zero meter deflection. Release OPERATE-CALIBRATE switch.

2-4. OPERATION AS A DC DIFFERENTIAL VOLTMETER

a. After completing preliminary operation, connect unknown voltage to input binding posts. If one side is grounded, always connect it to the lower input post (middle post).

b. Turn RANGE switch to lowest range that will allow an on-scale reading and note approximate value of unknown voltage as indicated on upper meter scale.

c. If meter reads to the left, turn AC - DC polarity switch to the negative position. The meter needle will deflect to the right. This is because polarity of unknown voltage is negative.

d. Noting the position of illuminated decimal light, set five voltage readout dials to approximate voltage determined in step b. For example, if approximate voltage is 35 volts, the decimal light between the B and C voltage readout dials will be illuminated. Therefore, set A dial to 3, B dial to 5, and C, D, and E dials to 0.

e. Set NULL switch to successively more sensitive null ranges, as indicated in figure 2-2, and adjust voltage readout dials for zero meter deflection in each null position. When the meter needle indicates to the right, the voltage under measurement is greater than the voltage set on the voltage readout dials. When the indication is to the left, the voltage is less than that set on the readout dials.

INPUT VOLTAGE RANGE	*RECOMMENDED NULL SETTING
50-500	10 then 1 (then 0.1 for voltages from 50 to 100 volts)
5-50	1 then 0.1 (then 0.01 for voltages from 5 to 10 volts)
0.5-5	0.1 then 0.01
0-0.5	0.1 then 0.01

*Any null range may be used with any input voltage range; recommended settings are those most useful.

Figure 2-2. RECOMMENDED NULL SETTINGS

f. Read unknown voltage directly from the five voltage readout dials.

2-5. OPERATION AS AN AC DIFFERENTIAL VOLTMETER

a. After completing preliminary operation, set AC-DC polarity switch to AC.

b. Connect unknown AC voltage to input binding posts.

c. Turn RANGE switch to lowest range that will allow an on-scale reading and note approximate value of unknown voltage as indicated on upper meter scale.

d. Noting the position of illuminated decimal light, set five voltage dials to approximate voltage determined in step c. For example, if approximate voltage is 35 volts, the decimal light between the B and C voltage dials

will be illuminated. Therefore, set A dial to 3, B dial to 5, and C, D, and E dials to 0.

e. Set null switch to 0.1 and then 0.01 volt, adjusting voltage dials for zero meter deflection in each position.

f. Read unknown voltage from the five voltage readout dials.

2-6. OPERATION AS A CONVENTIONAL VTVM

If it is desired to use the instrument as a VTVM only, additional ranges can be made available by converting the NULL ranges to VTVM ranges. This is made possible by setting the voltage readout dials to zero. Proceed as follows:

a. Perform preliminary operation procedures as stated in paragraph 2-3.

b. Consult figure 2-3, and select full scale voltage deflection desired. If the approximate value of the voltage to be measured is unknown, select the 500 volt range initially.

c. Set AC-DC polarity switch, RANGE switch, NULL switch, and voltage dials as indicated for the range selected.

d. Connect voltage to be measured to input binding posts. Deflection to the right indicates that an unknown DC voltage is of positive polarity. An unknown AC voltage will always cause deflection to the right.

e. Read voltage from upper or lower scale as listed in figure 2-3.

Full-Scale Deflection	AC-DC Polarity Switch	Range Switch	Null Switch	Voltage Readout Dials	Meter Scale
DC:					
500-0-500	DC	500	VTVM	No effect	Upper
50-0-50	DC	50	VTVM	No effect	Upper
5-0-5	DC	5	VTVM	No effect	Upper
0.5-0-0.5	DC	0.5	VTVM	No effect	Upper
10-0-10	DC	No effect	10	All zero	Lower
1-0-1	DC	No effect	1	All zero	Lower
0.1-0-0.1	DC	No effect	0.1	All zero	Lower
0.01-0-0.01	DC	No effect	0.01	All zero	Lower
AC:					
0-500	AC	500	VTVM	No effect	Upper
0-50	AC	50	VTVM	No effect	Upper
0-5	AC	5	VTVM	No effect	Upper
0-0.5	AC	0.5	VTVM	No effect	Upper
0-100	AC	500	1	All zero	Lower
0-10	AC	500	0.1	All zero	Lower
		50	1		
0-1	AC	500	0.01	All zero	Lower
		50	0.1		
		5	1		
0-0.1	AC	50	0.01	All zero	Lower
		5	0.1		
		0.5	1		
0-0.01	AC	5	0.01	All zero	Lower
		0.5	0.1		
0-0.001	AC	0.5	0.01	All zero	Lower

Figure 2-3. VTVM RANGES

2-7. MEASUREMENT OF VOLTAGE EXCURSIONS ABOUT A NOMINAL VALUE

a. After completing preliminary operation as stated in paragraph 2-3, set AC-DC polarity switch to desired position.

b. Connect voltage to be observed to input binding posts. If meter reads to the left, the voltage being measured is negative DC; set polarity switch to the negative position in this case. This will cause meter pointer to deflect to the right.

c. Set RANGE switch to lowest range which will give an on-scale meter indication and note nominal value of voltage indicated.

d. Set the five voltage readout dials to nominal voltage.

e. Turn NULL switch to lowest position that will allow voltage excursions to remain on scale.

f. Read voltage excursions from meter. Note that full scale right and left meter deflections are equal to the NULL voltage setting for DC measurements. For AC measurements, full scale right and left meter deflections are equal to the NULL voltage setting multiplied by the AC NULL MULT indicated by the RANGE setting. Figure 2-4 shows full scale AC deflections for the recommended settings of the range and null switches.

Range Switch Setting	Null Switch Setting	AC Null Multiplier	Full Scale AC Deflection (in volts)
500	1 0.1 0.01	X100	100 10 1
50	1 0.1 0.01	X10	10 1 0.1
5	1 0.1 0.01	X1	1 0.1 0.01
0.5	1 0.1 0.01	X0.1	0.1 0.01 0.001

Figure 2-4. FULL SCALE AC DEFLECTIONS

2-8. USE OF 803B WITH A RECORDER

Recorder output binding posts and an output level control are provided on the 803B for monitoring the excursions of an unknown voltage from the voltage indicated by the voltage dial settings. If the leakage resistance between the recorder and ground is less than 10,000 megohms, the accuracy of the 803B will be impaired. Also, both input posts of the recorder should be able to stand 500 volts DC to ground. Therefore, the John Fluke Model A-70 Potentiometric Recorder (manufactured by the Texas Instrument Co.) is recommended for this application. Set up the recorder as follows:

a. Connect A-70 recorder to 803B voltmeter with teflon leads as shown in figure 2-5.

CAUTION

Do not ground either of the 803B output terminals or either of the A-70 input terminals. If any of these terminals are grounded, current will be drawn from the 803B Kelvin-Varley voltage divider and the accuracy of the 803B will be completely destroyed.

b. After connecting the recorder, perform preliminary operation as stated in paragraph 2-3.

c. Check for excessive leakage as follows:

(1) Connect a dc voltage to the input of the 803B and differentially measure its potential in a recommended null range.

(2) Alternately connect and disconnect the recorder leads from the output terminals of the 803B while noting the meter needle deflection. More than one-scale division deflection indicates that excessive leakage has been introduced by the recorder. This will impair the accuracy of the 803B voltmeter.

(3) Disconnect the voltage.

d. After the leakage test has been successfully completed, short the input terminals of the 803B.

e. Set switches on the 803B voltmeter as follows:

AC-DC polarity	+ (positive)
RANGE	50
NULL	10
voltage read-out dials	10.000

The 803B meter will indicate full scale deflection. This provides up to a maximum of approximately 20 millivolts at the output terminals depending on the setting of the output level control.

f. Turn the output level control until the recorder deflection obtained is that desired to correspond to full scale deflection of the 803B.

g. Remove the short from the input terminals of the 803B. The 803B and the recorder are now ready for combined use. Proceed as instructed under paragraph 2-7.



*If the recorder should be jittery, it is suggested that a 1,000 ohm resistor be substituted for the shorting link.

Figure 2-5. RECORDER RECOMMENDED CONNECTION DIAGRAM

2-9. MEASUREMENT OF HIGH RESISTANCES

One of the important features of the 803B voltmeter is its ability to be used as a megohmmeter for rapidly measuring high resistances from 1 megohm to 250,000 megohms. The following equation may be used to compute the resistance in megohms of an unknown connected to the input binding posts:

$$R_x = 10\left(\frac{E}{E_m} - 1\right) \text{ megohms,}$$

where:

R_x = unknown resistance in megohms

E = voltage indicated by voltage readout dials

E_m = voltage indicated on meter

10 = megohms of input resistance of VTVM circuit on 10, 1, and 0.1 null range.

When connecting the unknown resistance to the input terminals, use short isolated leads to prevent measuring leakage resistance between the leads.

a. FROM 1 MEGOHM TO 500 MEGOHMS. For rapid measurement of resistances from 1 megohm to 500 megohms, proceed as follows:

(1) Perform preliminary procedure as stated in paragraph 2-3.

(2) Set RANGE switch to 500 and NULL switch to 10.

(3) Connect unknown resistance between input terminals.

(4) Adjust voltage readout dials for full scale meter deflection.

(5) Subtract 10.00 from the amount set on the voltage readout dials to find the resistance of the unknown in megohms.

b. FROM 500 MEGOHMS TO 5000 MEGOHMS. For rapid measurement of resistances from 500 to 5000 megohms, proceed as follows:

(1) Perform preliminary procedure as stated in paragraph 2-3.

(2) Set RANGE switch to 500 and NULL switch to 1.

(3) Connect unknown resistance between input terminals.

(4) Adjust voltage readout dials for full scale meter deflection.

(5) Subtract 1.00 from the amount set on the voltage readout dials and multiply the result by 10 to find the resistance of the unknown in megohms.

c. FROM 5,000 MEGOHMS TO 50,000 MEGOHMS. For rapid measurement of resistances from 5,000 to 50,000 megohms, proceed as follows:

(1) Perform preliminary procedure as stated in paragraph 2-3.

(2) Set RANGE switch to 500 and NULL switch to 0.1.

(3) Connect unknown resistance between input terminals.

(4) Adjust voltage readout dials for full scale meter deflection.

(5) Multiply the amount set on the voltage readout dials by 100 to find the resistance of the unknown in megohms.

d. FROM 50,000 MEGOHMS TO 250,000 MEGOHMS. To determine the value of an unknown resistance between 50,000 megohms and 250,000 megohms, proceed as follows:

(1) Perform preliminary procedure as stated in paragraph 2-3.

(2) Set RANGE switch to 500 and NULL switch to 0.1.

(3) Connect unknown resistance between input terminals.

(4) Adjust voltage readout dials for a convenient meter deflection.

(5) The resistance in megohms may be calculated by substituting the meter reading in volts (E_m, 0 to 0.1 volt on bottom scale) and the voltage readout dial setting (E) into the following equation:

$$R_x = 10\frac{E}{E_m} \text{ megohms}$$

2-10. NOTES ON MEASURING AC OR DC VOLTAGES

a. ADJUSTMENT OF 500 VOLT REFERENCE SUPPLY. The 500 volt DC reference supply may be adjusted (paragraph 2-3, step c) at any time deemed necessary without heed to the position of the switches and without removing any input or output connections. However, until the instrument has warmed up to an equilibrium temperature (about 1/2 hour), it should be adjusted prior to each specific measurement for best accuracy. When making prolonged measurements, allow one hour warmup time to insure that 500 volt reference supply does not shift during the final warmup phase.

b. GROUND LOOP PRECAUTIONS. Ground loop currents should be avoided to assure accuracy when making measurements. Potential differences are often found at different points on power system grounds. When this is the case, current may flow from the power system ground through the 803B and the equipment under measurement and back to the power system ground. To avoid this when system being measured is grounded, do not connect shorting link from lower input binding post to chassis ground post.

c. USE OF SHORTING LINK. A 0.47 uf capacitor (C1) is connected from the lower input binding post to the chassis ground post to reduce the effect of circulating AC currents from the transformer. In some cases, it is possible for C1 to acquire a charge. For example, C1 will become charged through leakage resistance over a period of time if there is no external connection to the input terminals and the controls are set as follows: range to 500, null to any null range, polarity to +, and voltage readout dials to several hundred volts. This condition may cause an error on low level measurements (under 5 volts) due to C1 discharging through the Kelvin - Varley divider. Connecting the shorting link from the lower input post to the ground post will discharge C1 and thus prevent an inaccurate indication.

2-11. NOTES ON MEASURING DC VOLTAGES

a. RECOMMENDED NULL RANGES FOR DC MEASUREMENTS. Certain null ranges are recommended for use with each setting of the RANGE switch for the following reasons. With the RANGE switch at 500 volts the last voltage readout dial (E) changes the reference voltage in steps of 0.01 volt. Therefore, the unknown voltage would have to be an exact multiple of 0.01 volt if a null is to be obtained on the 0.1 or 0.01 volt NULL range. Furthermore, it is unlikely that an unknown voltage of a few hundred volts will be stable within 10 millivolts. Finally, the regulation of the reference supply is approximately ±0.0025% (±0.0125 volt) for a 10% change in line voltage. Although this is more than adequate when the instrument is used in the recommended way, a badly fluctuating line voltage may cause the 803B to meter the regulation of its own 500 volt reference supply. For example, when measuring 500 volts a line change of 10% may cause the 500 volt reference supply to change as much as 12.5 mv. Although this is small, the 803B will indicate full scale for a change as little as 100 mv or 10 mv if attempting to use the 0.1 or 0.01 null ranges.

b. EFFECT OF AC COMPONENTS ON DC MEASUREMENTS. An AC component of several times the unknown DC may be present on the unknown and the 803B will always indicate well within the specifications for frequencies over a few hundred cycles. An AC component may have an adverse effect if it is of a low frequency or if it has a frequency that is a multiple or submultiple of the chopper frequency. A double section low pass filter (R201, C201, R202, and C202) is used at the input of the null detector to reduce any AC present on the DC being measured. At lower frequencies, this low pass filter is less effective and the magnitude of the AC component is more significant. When the frequency is very close to a multiple or submultiple of the chopper frequency (approximately 60 cycles), the meter needle will oscillate at the difference frequency. For example, a 60 cycle AC voltage that is 5% of the input voltage will cause an error of approximately 0.01% which is well within the specifications. At low frequencies other than 60 cycles, a larger AC component can be tolerated. Also, since the input attenuation is less for the more sensitive null settings, the accuracy may be affected only on the more sensitive null settings. If AC components that affect the accuracy are ever encountered, additional filtering will be required. For an AC of a single frequency, a twin-T filter is effective and has the advantage of low total series resistance. For an AC variable frequency, an ordinary low pass filter may be used. In either case, high quality capacitors of high leakage resistance should be used.

c. MEASUREMENT OF NEGATIVE DC VOLTAGES. Because of a polarity switch, voltages which are negative with respect to ground as well as the more commonly encountered positive voltages may be measured with equal facility. If the upper input post is connected to the metal case or line ground, either at the 803B or at the source under measurement, the accuracy of the voltmeter may be reduced. However, with the polarity switch the upper input post never has to be connected to ground. If the unknown voltage is grounded, always connect the grounded side to the lower input post (middle post) and use the polarity switch to obtain the proper result.

2-12. NOTES ON MEASURING AC VOLTAGES

a. ERRORS DUE TO DISTORTION. The AC to DC converter in the 803B is an average measuring device calibrated in RMS. The converter will put out a DC voltage that is proportional to 1.11 times the average value of the AC input voltage. Thus, if the input signal is not a true sinusoid, the 803B reading is probably in error because the ratio of RMS to average is usually not the same in a complex wave as in a sine wave. The magnitude of the error is dependent on magnitude of the distortion and on its phase and harmonic relationship with respect to the fundamental. Figure 2-6 indicates how the accuracy will be affected by various harmonics for different percentages of distortion. If the distortion present in the signal is composed of even harmonics and is less than 2%, the error between the 803B reading and true RMS is fairly minor. A larger error can occur if the distortion is composed of odd harmonics, especially the third harmonic. Note that for 2% of third harmonic distortion the error in the reading could range from 0 to 0.687%.

Harmonic	% Distortion	% Error From True RMS*	
		Maximum Positive	Maximum Negative
Any even harmonic	0.1	0.000	0.000
	0.5	0.000	0.0001
	1.0	0.000	0.005
	2.0	0.000	0.020
Third harmonic	0.1	0.033	0.033
	0.5	0.167	0.168
	1.0	0.328	0.338
	2.0	0.667	0.687
Fifth harmonic	0.1	0.020	0.020
	0.5	0.099	0.101
	1.0	0.195	0.205
	2.0	0.380	0.420

*Error depends upon phase relationship between harmonic and fundamental, i.e. error can be any value between maximum positive and maximum negative, including zero.

Figure 2-6. PERCENT ERROR DUE TO HARMONIC DISTORTION

b. ERRORS DUE TO GROUNDING. In the 803B there is a 0.47 uf capacitor connected from the lower input terminal (middle post) to chassis ground. If it is desired to make measurements where the voltage to be connected to the lower input terminal is not at ground potential, a line cord adapter must be used to isolate the 803B chassis from line ground. Otherwise, the 0.47 uf capacitor would place an AC load on the circuit being measured.

c. INTERNAL CONVERTER NOISE. When the instrument is shorted in the AC mode, the converter may produce a residual noise output of approximately 100 uv. This noise voltage will cause an insignificant error as long as AC input signals of 1 mv or larger are applied to the instrument. Figure 2-7 shows a typical half wave of the signal voltage at the output of the converter amplifier. It is easily seen that the noise contributes very little to the average value of the signal and is well within the 2.7% accuracy of the instrument at 1 mv.



Figure 2-7. SIGNAL VOLTAGE WITH CONVERTER NOISE

SECTION III

THEORY OF OPERATION

3-1. GENERAL

a. Figure 3-1 shows the block diagram for the 803B AC/DC Differential Voltmeter. As seen in this figure, the circuit is mainly composed of an AC attenuator, an AC to DC converter, a DC attenuator, a null detector, a Kelvin-Varley divider, a range divider, a 500 volt DC reference power supply, and a null detector power supply. Refer to the functional schematic following Section VI for more detail. This schematic is designed to aid in the understanding of circuit theory and trouble-shooting. The signal flow is from left to right and the components are laid out in a functionally logical manner.

b. The overall operation of the voltmeter may be summarized as follows. The combination of the DC attenuator and the null detector form a very sensitive wide range DC VTVM. A DC differential voltmeter is created by connecting this DC VTVM in series with a precise internal DC voltage appearing across the Kelvin-Varley voltage divider. For AC measurements, the AC attenuator and the AC to DC converter unite to produce a DC voltage that is proportional to the AC input voltage. This DC voltage is then applied to the DC VTVM or the DC differential voltmeter.

c. To measure the approximate value of a DC voltage, the unknown voltage is connected to the DC VTVM. The DC attenuator reduces the maximum voltage for each range to a signal of 10 millivolts. This 10 mv signal is applied to the null detector and causes 100 microamperes to flow through the meter for full scale deflection. To accurately measure a DC voltage, the unknown voltage is connected to the DC differential voltmeter. The internal voltage is then adjusted by means of the Kelvin-Varley voltage divider until it matches the unknown voltage as indicated by the null detector.

d. All AC measurements are made by first converting the AC input voltage to a DC voltage. The AC to DC converter provides an output of 5 volts DC when the maximum voltage for each range is applied to the 803B. To measure the approximate value of an AC voltage, the output of the converter is connected directly to the DC VTVM. In this case, the DC attenuator always gives a reduction of 500 to 1. Thus 10 mv is supplied to the null detector for full scale deflection when the maximum voltage for each range is applied to the 803B. To accurately measure an AC voltage, the output of the converter is connected to the DC differential voltmeter which operates essentially the same as for DC measurements.

e. In order to provide for a more complete understanding of the 803B voltmeter, the following paragraphs describe each section of the circuit in detail.



Figure 3-1. 803B AC/DC DIFFERENTIAL VOLTMETER BLOCK DIAGRAM

3-2. DC ATTENUATOR

a. In the DC VTVM mode, the resistance of the DC attenuator and thus the input resistance of the voltmeter is 50 megohms (R301 through R310) For full scale deflection 10 mv must be applied to the null detector. The necessary reduction is provided by four positions on the DC attenuator that are selected by range switch section S2C.

b. In the DC differential mode, the resistance of the DC attenuator is 10 megohms (R305 through R310) for the 10, 1, and 0.1 null ranges and 1 megohm (R306 through R310) for the 0.01 volt null range. However, this is not the input resistance of the voltmeter. The input resistance is determined by dividing the terminal voltage of the unknown by the amount of current drawn from the unknown. The current drawn from the unknown is equal to the difference between the unknown terminal voltage and the internally known voltage divided by the resistance of the DC attenuator. The equation for input resistance can hence be written as:

$$R_{in} = \frac{E_u}{I_u} = \frac{E_u R_a}{|E_u - E|} = \frac{E_s (R_a + R_s)}{|E_s - E|} - R_s$$

where:

R_{in} = input resistance of voltmeter

E_u = $E_s - I_u R_s$ = terminal voltage of unknown

I_u = current drawn from unknown

E_s = source voltage of unknown

R_s = source resistance of unknown

R_a = resistance of DC attenuator

E = voltage indicated by voltage readout dials

$| \ |$ = absolute value (magnitude only)

Thus, the input resistance is infinite at null when E is equal to E_u and E_s.

c. For full scale deflection of 10, 1, and 0.1 volts, the voltage difference (unknown voltage minus reference voltage) must be reduced by an attenuator. This reduction is provided by three positions on the DC attenuator that are selected by null switch section S3A. On the 0.01 volt null range, the voltage across the DC attenuator is fed directly to the null detector.

d. In the AC VTVM mode, null switch section S3A and AC-DC polarity switch section S5L provide connection to one position on the DC attenuator regardless of where the range switch is set. The converter output is thus reduced by a factor of 500 to 1. For full range input on each range, the 5 volt DC output of the converter is therefore reduced to the 10 mv required by the null detector for full scale deflection.

e. In the AC differential mode, the voltage difference (converter output voltage minus reference voltage) must be reduced by the DC attenuator before it is applied to the null detector. This reduction is provided by the same positions on the DC attenuator as for DC differential measurements.

3-3. NULL DETECTOR

a. GENERAL. The null detector is a fixed gain device containing three resistance-capacitance coupled voltage amplifier stages with a high amount of negative current feedback. With high negative current feedback, the output current is approximately equal to the signal voltage divided by the impedance of the feedback network regardless of the amplifier characteristics. The high negative feedback also makes the amplifier relatively insensitive to the gain changes in individual tubes due to aging and replacement. The output current from the null detector is indicated on a meter that has taut-band suspension. This suspension does away with all friction associated with meter pivot stickiness. Thus, any tendency for the meter pointer to stick at one point of the scale and then jump to another point is completely eliminated.

b. OPERATION. At the input to the null detector R201, C201, R202, and C202 form a double section low pass filter that reduces any AC component present on the DC voltage being measured. The difference between the voltage appearing at the output of the filter and the voltage developed across the feedback network is converted to an alternating voltage by G1, a 60 cycle chopper. This chopped voltage is amplified by V202, V203A, and V203B. During half the chopper cycle the output of the amplifier is clamped to approximate null detector common potential by G1 while during the other half the output is filtered by C212 to provide a DC current for the meter. When the chopper provides connection between contacts 1 and 7 a voltage is developed across feedback network R218 and R219 that is proportional to the meter (output) current. This feedback voltage effectively reduces the magnitude of the voltage that is chopped and applied to the input of the amplifier. The impedance of the feedback network (R218 and R219) is adjustable between 93.1 and 103.1 ohms. Since the output current is approximately equal to the signal voltage divided by the impedance of the feedback network, a 10 mv signal voltage indicates an output current of 97.8 to 107.4 ua. However, there is a loss due to finite amplifier gain and filtering that leaves the output current around 100 ua which can be set accurately by means of the feedback network. Thus, current feedback makes the output current essentially proportional to the signal voltage. For full scale deflection, a 10 mv signal voltage will cause 100 ua to flow through the meter.

c. EFFECT OF AC COMPONENTS. The only AC voltage component that will reduce the accuracy of the 803B is one that either saturates the chopper-amplifier or one that beats with the chopper frequency. Since the voltage required for saturation is greater than that required for beating, the null detector is most sensitive to an AC component with a frequency that is submultiple or a low multiple of the chopper frequency. However, this is easy to detect because the meter will beat at the difference frequency. The low pass filter at the input of the chopper-amplifier will attenuate any AC component.

The magnitude of the AC voltage appearing at the output of the filter depends on both its amplitude and frequency before filtering. For all practical purposes, one should never encounter any trouble above a few hundred cycles. Below this, the filter may not attenuate the AC component enough. However, this is not as bad as it appears. A 60 cycle AC voltage that is 5% of the input voltage will cause an error of approximately 0.01% which is well within specifications. If AC components that affect accuracy are ever encountered, additional filtering as set forth in paragraph 2-11 will eliminate the problem.

d. GAIN AND ZERO ADJUSTMENTS. Variable resistor R227 in the null detector power supply provides a means of adjusting the output current of the amplifier to zero when there is no input signal. The gain of the amplifier is adjusted by means of R219 in the feedback circuit.

e. RECORDER OUTPUT. The recorder output is picked off divider string R222, R1, and R223. Output level control R1 provides a means of adjusting the output voltage up to a maximum of approximately 20 millivolts at full scale deflection. The voltage at the output terminals is proportional to the meter reading.

3-4. 500 VDC REFERENCE POWER SUPPLY

a. When the 803B is used for AC or DC differential voltage measurements, an internal DC voltage is nulled or matched against the unknown voltage. An extremely accurate reference voltage is therefore required. This is obtained from the 500 volt DC reference supply.

b. A half wave voltage doubler consisting of five diodes (CR101, CR102, CR103, CR106, and CR107) and a filter network (R109, R110, C101, and C102) supply unregulated DC voltage to series passing tube V101. The voltage is regulated by comparing the voltage from reference tube V102 with a voltage tapped off a divider string (R123, R124, R121, and R2) in a differential amplifier V104. The output of differential amplifier V104 is fed to differential amplifier V105 which drives the grid of series passing tube V101. In this way the voltage drop across the passing tube is controlled such that the reference supply is maintained at 500 volts.

c. The reference voltage is passed to the Kelvin-Varley divider as follows for positive and negative DC settings of the AC - DC polarity switch. With the range switch set to 500, range switch sections S2B and S2F connect 500 volts to the Kelvin-Varley divider. In the 50, 5, and 0.5 volt positions, range resistors controlled by S2E divide the reference voltage to 50, 5, and 0.5 volts. These voltages are switched to the Kelvin-Varley divider by S2F. When the AC-DC polarity switch is set to AC, section S5G provides connection to only the range resistors that divide the reference to 5 volts. This 5 volts is then passed to the Kelvin-Varley divider by section S5H. The voltage applied to the Kelvin-Varley divider is always 5 volts for AC because the AC to DC converter always supplies up to a maximum of 5 volts to the DC attenuator. The 50, 5, and 0.5 volt range resistor networks are set accurately during calibration by means of R323, R326, and R329.

d. Variable resistor R121 is used during calibration to set the reference supply to 500 volts with calibrate control R2 set at its center of rotation. This allows the reference supply to be adjusted to 500 volts by me of the calibrate control at any time deemed necessary. With the operate-calibrate switch held at calibrate, a fixed percentage of the reference supply is compared to the precise potential of an internal standard cell or a Zener reference diode (in the /AG models). Any difference in potential is fed to the null detector so that the reference supply can be set with the calibrate control. The fixed percentage of the reference supply is set accurately during calibration by means of R318.

e. For proper operation a highly stable and accurate balance of amplification must be maintained between the two halves of differential amplifier V104. The filament supply for V104 must be regulated to maintain this balance. Regulation is provided by a transistor regulator which supplies constant voltage to the filament of V104. The filaments of the AC to DC converter tubes (V501 and V502) are also supplied by this regulator. A filtered full wave rectifier (CR104, CR105, and C103) which is regulated by a three transistor network (Q1, Q2, and Q3) supplies the regulated DC filament voltage. One side of the filaments are connected to the reference supply common (0 volts) while the other side is maintained at approximately 5.9 volts through the emitter-collector junction of Q3. The output of Q1 drives a Darlington connections of Q2 and Q3. Any variation in the unregulated supply causes a corresponding change in the voltage across the emitter-collector junction of Q3 so that the filament voltage of V104, V501, and V502 remains stable.

3-5. KELVIN-VARLEY DIVIDER

a. In order to null unknown voltages, each one of the four precision voltages available from the reference supply must be made adjustable. The five Kelvin-Varley decade resistor strings, R401 through R449 accomplish this function.

b. Note that each string, with the exception of the first, parallels two resistors of the string that preceeds it. Between the two wipers of S6 (voltage dial A) then, there is a total resistance of 40K (80K paralleled by 80K). With the RANGE switch in the 500 volt position, a total voltage of 100 volts DC will appear across these two wipers. Also, there will be 10, 1, and 0.1 volts DC across the wipers of S7, S8, and S9 respectively. Voltage dial E (S10) picks increments of 0.01 volts DC from the last decade. These voltages are reduced by a factor of 10 for each lower voltage range.

c. All the resistors of each decade are matched and all decades are matched for each instrument, providing an overall divider accuracy of 0.01% absolute.

d. With the NULL switch in any null range, the output of the Kelvin-Varley divider is connected in series with the DC attenuator as seen from the DC terminals. Also, the null detector operates with a common that is above or below (depending on the setting of the polarity switch) the potential of the lower input binding post by the amount set on the voltage readout dials.

3-6. AC TO DC CONVERTER

a. GENERAL. The AC to DC converter is essentially an operational amplifier containing three resistance-capacitance coupled amplifier stages with high negative feedback. The amplifier achieves a midband loop gain of approximately 70 db with a virtually flat frequency response from 20 cps to 10 kc. The high negative feedback makes the amplifier practically noise free and relatively insensitive to gain changes in individual tubes due to aging and tube replacement. At the output of the amplifier, full-wave rectification is used to return negative feedback to the grid of the first amplifier tube. Halfwave rectification and filtering is utilized to produce a DC voltage that is proportional to the average value of the AC input voltage. The output, however, is calibrated to indicate the rms value of a pure sine wave.

b. OPERATION. All AC measurements are made by first converting the AC input voltage to a DC voltage. The converter provides a DC output of 5 volts when full range voltage is applied to the 803B in each range. In the 5 volt AC position, range switch sections S2G and S2H connect the input binding posts directly to the converter input. In this case, the converter feedback is of such a value that the DC output voltage is equal to the rms value of the converter input AC voltage. In the 50 and 500 volt AC positions, input attenuators reduce the unknown AC by a factor of 10 and 100 respectively. This provides a maximum of 5 volts AC input to the converter for full range input to the 803B. In the 0.5 volt AC position, range switch section S2I connects to feedback resistors that allow the converter to produce a DC output that is equal to ten times the AC input. Thus, an output of 5 volts DC is provided for a full range input of 0.5 volts AC.

c. NULL INDICATIONS. When making AC differential measurements, the null range used times the applicable AC null multiplier must be used to represent full scale on the 803B meter. This is due to the way that the converter is constructed. When the range switch is set to 500, the AC attenuator reduces the input voltage by 100 to 1 before it is converted to DC and applied to the DC attenuator. Thus, the AC null multiplier for the 500 volt range position is X100. For example, when the range switch is set to 500 and the null switch is set to 0.01, full scale meter deflection represents a one volt (100 x 0.01) difference between the unknown voltage and the amount set on the voltage readout dials. By similar reasoning, the multiplier for the 50 and 5 volt positions are 10 and 1 respectively. When the range switch is set to the 0.5 volt position, the converter amplifies the input voltage by ten before it is converted to DC and applied to the input attenuator. Thus, the AC null multiplier for the 0.5 volt position is X0.1.

d. ADJUSTMENTS. For 0.5 volt converter gain, R536 at the output of the converter is adjusted. The gain of the amplifier for the 500, 50, and 5 volt ranges is adjusted by means of R541 in the feedback network. The high frequency response of the amplifier input is adjusted by means of C504 while C519 adjusts the high frequency response of the 0.5 volt feedback circuit. The attenuation of the 500 volt attenuator is adjusted with R534 and the attenuator high frequency response is adjusted with C523. The attenuation of the 50 volt attenuator is adjusted with R503 and the attenuator high frequency response is adjusted with C501.



Figure 3-2. DC FUNCTION OF AC-DC POLARITY SWITCH

3-7. AC - DC POLARITY SWITCH.

a. The AC - DC polarity switch is provided for selecting either the AC or DC mode of operation. When the AC - DC polarity switch is set to AC, the AC to DC converter is switched into the circuit by sections S5I and S5K. Also, sections S5G and S5H are used to switch 5V DC to the Kelvin-Varley divider. When in the AC VTVM mode, S5L is used to provide the proper attenuation for the DC attenuator.

b. The AC - DC polarity switch may be set to either of two positions, positive or negative, for the DC mode of operation. As seen in figure 3-2, the AC - DC polarity switch does not just reverse the input posts when going from the positive to negative DC position. It reverses the meter and the internal reference supply. If the instrument did not contain positive and negative DC positions, the grounded side of any unknown voltage that is negative with respect to ground would have to be connected to the upper input binding post. This would ground the upper post and effectively place C1 (a 0.47 uf capacitor) across the input terminals. Even if C1 was disconnected, there would still be considerable capacitance across the input due to transformer winding capacitance and stray wiring capacitance. With this capacitance across the circuit being measured several problems could arise. The polarity switch provides equal convenience in measuring positive or negative voltages without the occurrence of these problems.

3-8. NULL DETECTOR POWER SUPPLY

A half wave rectifier system consisting of diode CR201 and a filter network (C214A, R228, and C214B) provides an unregulated DC voltage. This voltage is regulated by using an OA2 tube (V204) and a dropping resistor R229 in order to maintain a fairly stable B+ supply for the null detector. The chopper coil supply and the filament supply for V202 and V203 is obtained from a 6.3 volt winding. Variable resistor R227 along with divider resistors R225 and R226 provide a compensating voltage for the purpose of adjusting the null detector to zero with R227 when there is no signal input.

SECTION IV

MAINTENANCE

4-1. GENERAL

The 803B AC/DC Differential Voltmeter seldom requires any maintenance. Without extreme abuse, all that should be required is occasional cleaning, tube replacement, and calibration. Preventive maintenance consists only of preventing any leakage as discussed in paragraph 4-2. A discussion of troubleshooting along with a troubleshooting chart, component location diagrams, and a tube voltage chart are provided in paragraph 4-3. Paragraph 4-4 delineates the equipment and procedures necessary to calibrate the instrument.

4-2. PREVENTIVE MAINTENANCE

a. The accuracy of the 803B is adversely affected by excessive electrical leakage from the input of the null detector to either ground or the 500 volt reference supply. This leakage becomes evident when the RANGE switch is set to 500, NULL switch to 0.1, voltage readout dials to 490.00, and no input at the binding posts. The leakage indicated on the meter should be not more than one-tenth of full scale. Special care has been taken to prevent leakage across certain critical switch wafers and areas of some printed circuit boards due to moisture from condensation. The printed circuit boards have been coated with Humi-Seal 1B12 (manufactured by Columbia Technical Corp. of Woodside, N. Y.). The RANGE, NULL, OPERATE-CALIBRATE, and AC-DC polarity switches have been dipped in Dow Corning silicone oil. Accumulations of dust and foreign matter will cause internal leakage, and should be removed as often as necessary, depending on environmental operating conditions. Blowing the instrument out with low pressure, clean, dry air will remove most accumulations. Particular attention should be paid to the binding posts and wiring, and the NULL, RANGE, OPERATE-CALIBRATE, and AC-DC polarity switches.

b. After blowing the instrument out, the binding posts, insulators, and front panel may be cleaned with a rag saturated in anhydrous denatured ethyl alcohol. When necessary, wash all exposed dielectric surfaces of the NULL, RANGE, OPERATE-CALIBRATE, and AC-DC polarity switches with this alcohol using a small, stiff-bristled brush.

CAUTION

Do not use Metriclene, acetone, lacquer thinner, or any other methyl ethyl ketones since they will react with the Lexan rotor on the CTS plastic switches.

After washing, recoat the exposed switch insulating material with a solution of Dow Corning 200 having a viscosity between 5 and 20 centistokes. This prevents leakage due to moisture on these surfaces.

4-3. TROUBLESHOOTING

a. GENERAL. To assist in localizing most troubles which might occur, a troubleshooting chart (figure 4-1) lists the causes and remedies for a number of symptoms. Since failure of the 803B is usually due to tube failure, it is recommended that tube substitution be tried before any other tests are made. However, the 803B is conservatively designed and should require very infrequent tube replacement. At certain times, a check of the DC pin voltages in the tubes (figure 4-4) is also useful. As an aid to troubleshooting, all components may be located by referring to the figures shown in Section V. An understanding of the theory of operation (Section III) and frequent reference to the functional schematic will be of great value in troubleshooting.

WARNING

Use extreme care when working inside the instrument while it is on. All metal components on the null detector board will be at a voltage close to that indicated by the voltage readout dials.

SYMPTOM	PROBABLE CAUSE	REMEDY
Drift of the 500 volt DC reference supply evidenced by the continual need for resetting with the CALIBRATE control.	V102, V104, or V105 defective.	Check V102, V104, and V105 by replacement.
	One of the sampling string resistors (R123, R124, R121) is changing value rapidly as the instrument warms up.	Locate faulty resistor by heating slightly with a soldering iron held near the resistor while observing the 500 volt DC calibration.
	Drifting standard cell EMF possibly caused by previous shorting or inverting of the cell. (803B and 803BR)	Allow time for the standard cell to stabilize. Several hours should be sufficient.
Cannot calibrate 500 volt DC reference supply. Meter cannot be brought to zero with CALIBRATE control.	Excessive aging of V102.	Check V102 by replacement.
	Out of calibration.	Recalibrate per paragraph 4-4.
	One or more resistors in 500 volt DC sampling string has shifted in value.	Recalibrate per paragraph 4-4 and observe stability for 48 hours. If 500 volt DC reference supply remains stable replacement of resistor is unnecessary.
	Standard cell EMF has shifted. (803B and 803BR)	Recalibrate instrument and observe stability of reference supply. Replacement of the standard cell may be necessary.
Measurements are out of tolerance on one range other than the 500 volt range.	A reference supply output range resistor on the range resistor printed circuit board is out of tolerance.	If the trouble occurs in the 50 volt range, R324 has shifted; in the 5 volt range, R325 or R327 has shifted; in 0.5 volt range, R328 or R330 has shifted. It may be possible to correct by recalibration. If not, replace faulty resistor.
Measurements are out of tolerance on all ranges other than the 500 volt range.	R320 or R321 has shifted in value.	It may be possible to correct all range voltages by recalibration. If not, replace faulty resistor.
Measurements are out of tolerance on any range when the Kelvin-Varley divider is dialed to any setting other than 499910.	One of the Kelvin-Varley divider resistors is out of tolerance.	Measure the voltage drop across each Kelvin-Varley resistor with another John Fluke Differential Voltmeter. Begin by setting RANGE switch to 500 volts and the voltage readout dials to 499.910. Reference to the schematic diagram will show that there should be 100, 10, 1, 0.1, and 0.01 volts respectively across each resistor of the A, B, C, D, and E decades, except for the two resistors of each decade that are paralleled by the following decade. Across these two resistors, there should be 50, 5, 0.5, and 0.05 volts, respectively. Measure all voltages ±0.05%. Remember that if one resistor in a decade has increased or decreased appreciably, the voltage drop across all other resistors in the decade will be slightly affected also.
Instrument is out of specifications on all ranges.	Resistors R306, R307, R308, R309 or R310 out of tolerance.	Check and replace faulty resistor.

Figure 4-1. TROUBLESHOOTING (sheet 1 of 2)

SYMPTOM	PROBABLE CAUSE	REMEDY
Meter rattle, drift, or error is observed on all null ranges.	V202 or V203 faulty.	Check V202 and V203 by replacement.
	Chopper G1 faulty.	Replace chopper.
	Moisture or dirt on printed circuit boards or switches.	Clean instrument.
NOTE: Assuming all DC measurements are normal, the following symptoms are common to AC measurements only.		
Measurements are out of tolerance on 500 volt AC range only.	Out of calibration.	Recalibrate per paragraph 4-4d (1) and 4-4d (6). DC calibration is not necessary.
	One or more resistors in 500 volt AC attenuator has shifted in value.	Recalibrate per paragraph 4-4d (1) and 4-4d (6). DC calibration is not necessary. Recheck calibration after 48 hours and if attenuator has remained stable, replacement of resistor is unnecessary. If attenuator does not remain stable, or calibration is not possible, replace faulty resistor.
Measurements are out of tolerance on 50 volt AC range only.	Out of calibration.	Recalibrate per paragraph 4-4d (1) and 4-4d (8). DC calibration is not necessary.
	One or more resistors in 50 volt AC attenuator has shifted in value.	Recalibrate per paragraph 4-4d (1) and 4-4d (8). DC calibration is not necessary. Recheck after 48 hours and if attenuator has remained stable, replacement of resistor is unnecessary. If attenuator does not remain stable or if calibration is not possible, replace faulty resistor.
Measurements out of tolerance on all AC ranges.	Out of calibration.	Recalibrate per paragraph 4-4d.
	V501 or V502 faulty.	Check V501 and V502 by replacement.
Measurements out of tolerance at a specific frequency.	Out of calibration.	Recalibrate per paragraph 4-4d.
	Faulty frequency compensation capacitor.	Locate faulty capacitor and replace. If trouble occurs on all ranges, check C504. If trouble occurs on 500 volt range only, check C523, C524, and C525. If trouble occurs on 50 volt range only, check C501 and C502. If trouble occurs on 500, 50, and 5 volt range, check C521. If trouble occurs on 0. 5 volt range check C519 and C520.

Figure 4-1. TROUBLESHOOTING (sheet 2 of 2)

b. TUBE REPLACEMENT. Replacement of tubes will not normally necessitate complete recalibration of the 803B. If V202 or V203 is replaced, calibrate the null detector as set forth in paragraphs 4-4c. (1) and 4-4c. (2). Replacement of V101, V102, V104, or V105 will necessitate calibration of the reference supply per paragraphs 4-4c. (1) and 4-4c. (3). If V501 or V502 is replaced, calibrate the AC to DC converter as in paragraph 4-4d.

c. COMPONENT REPLACEMENT. Should it ever become necessary to replace a component on a printed circuit board, proceed as follows:

(1) Clean soldered area around component with methyl ethyl ketone.

(2) Remove part and install new component.

(3) Remove flux with du Pont Freon PC.

(4) Allow to dry for 10 minutes. When it is cool or humid, it may be necessary to place area under a lamp to ensure thorough drying.

(5) Coat any uncoated areas around R305 through R310 on the Range Resistor Board and around the input to the Null Detector Board (tube V202, EF-86/6267, and chopper) with Humi-Seal 1B12.

d. KELVIN-VARLEY RESISTOR REPLACEMENT. All the resistors of the first three decades (R401 to R406, R407 to R417, and R418 to R428) are matched and these three decades are matched for each instrument. If it becomes necessary to replace a Kelvin-Varley resistor, the instrument model and serial number as marked on the name plate and all information stamped on the

resistor must be sent to Fluke along with the purchase order for the particular resistor needed. This ensures that a resistor compatible with the matched resistor group within the instrument is used. The Kelvin-Varley resistors are very stable and precise; resistance is clearly defined; therefore, they must be handled with care. This is especially true of the varnished-dipped-card resistors.

CAUTION

Pick up card resistors between ends of card. Never touch the wire on the cards as damage to the resistor could possibly result.

e. STANDARD CELL PROBLEMS. The standard cell of the 803B and 803BR deserves special consideration if it is suspected of being faulty:

(1) The standard cell used in the Model 803B and 803BR is a miniature low hysteresis unit which has excellent long term stability and negligible temperature hysteresis. (Hysteresis is a temporary increase in EMF immediately following a decrease in temperature; this effect should not be confused with temperature coefficient). Under normal conditions this cell should last from 8 to 15 years. In rare instances, failure has occurred in less than 2 years. End of life is usually marked by an increase in temperature hysteresis effect. That is, reading errors in excess of 0.025% will result when the same voltage is read with the 803B hot and cold. Should replacement of the cell become necessary for any reason, the instrument must be recalibrated (basic 500 volt range only), since the EMF of different cells may be different by as much as 0.05% and each instrument is calibrated to its own particular standard cell. Refer to the recalibration instructions in this case.

(2) Failure of the standard cell may occur if subjected to below freezing temperature. The electrolyte will freeze at 1°F and operation below 32°F is definitely not recommended. The life of the cell also will be greater is the 803B is not operated at elevated temperature. The 8 to 15 year figure holds for operation of the instrument in normal room temperature.

(3) The EMF of the standard cell will change if the cell has been inverted, or if the cell has been inadvertently short-circuited. If the EMF has changed, the 803B will naturally be out of calibration on all ranges. In either case, the cell will return to its original EMF. If the cell were inverted or shorted for only a few seconds, the 803B should be able to measure voltages within specifications after several hours recovery time.

f. DECIMAL LAMP REPLACEMENT. The decimal lamps are normal 6.3 volt pilot bulbs. To prolong their life these bulbs are operated from a 5 volt transformer winding. However, these bulbs do occasionally fail. To replace, proceed as follows:

(1) On cabinet models, remove screws at back of cabinet and slide instrument out of case.

(2) Remove four screws that hold front panel assembly to chassis.

(3) Being careful to avoid wiring damage, gently lift front panel assembly from instrument and set face down in front of instrument.

(4) Remove screws holding range resistor printed circuit board and Kelvin-Varley printed circuit board to front panel assembly.

(5) Push these printed circuit boards aside enough to allow access to pilot light holders.

(6) Remove pilot light holder from bracket by applying pressure to each side of holder.

(7) Remove cardboard light shield and replace pilot light.

(8) On rack models, remove screws holding cover of instrument and set cover aside.

(9) Remove pilot light holder from bracket by applying pressure to each side of holder.

(10) Remove cardboard light shield and replace pilot light.

4-4. CALIBRATION

a. GENERAL. The 803B can be calibrated as often as deemed necessary. However, it is recommended that Zener diode models be calibrated every three months and standard cell models be calibrated every six months. For special applications where extreme accuracy is required, it may be desired to calibrate the instrument more frequently. Calibration should be accomplished in a draft-free area with ambient temperature of 72 (±3)°F for maximum accuracy under laboratory operating conditions.

RECOMMENDED EQUIPMENT	SPECIFICATIONS REQUIRED
DC CALIBRATION: Fluke 301C or 301E Power Supply Eppley Standard Cell 100A Leeds and Northrup 2430A Electro Scientific Industries Special Precision Voltage Divider X194 Any single pole push button switch with fine silver contacts Any double pole push button switch with fine silver contacts Any 5.6 (±10%) Ω resistor Any 56 (±10%) Ω resistor	The equipment used must provide 500, 50, 5, and 0.5 volts with an accuracy of 0.01%.
AC CALIBRATION: Any Fluke Model 800 series Differential Voltmeter Fluke 301C or 301E Power Supply Elin VC - 555A Oscillator Fluke 540A Transfer Standard	The equipment used must provide 500, 50, 5, and 0.5 volts AC at 400 cycles and 10 kilocycles with an accuracy of at least 0.05% and with less than 0.1% total harmonic distortion.

Figure 4-2. CALIBRATION EQUIPMENT

b. The calibration procedure is divided into two parts: DC Differential Voltmeter calibration (paragraph 4-4c) and AC to DC Converter calibration (paragraph 4-4d). The DC Differential Voltmeter calibration must be performed prior to AC to DC Converter calibration. The recommended equipment and specifications required for calibration are shown in figure 4-2. All controls may be located with the aid of figure 4-3. The recommended calibration set-up is shown in figure 4-5 for DC Differential Voltmeter Calibration and in figure 4-6 for AC to DC Converter calibration.

c. DC DIFFERENTIAL VOLTMETER CALIBRATION. The Bureau of Standards will certify the Eppley 100A



Figure 4-3. ADJUSTMENT LOCATIONS

Symbol & Type	Pin 1	Pin 2	Pin 3	Pin 4	Pin 5	Pin 6	Pin 7	Pin 8	Pin 9
V101, 6BQ5	No Conn.	495	500	Heater voltage 6.3 volts ac		No Conn.	680 to 730	No Conn.	680 to 730
V102, OG3	85	0	Int. Conn.	0	85	Int. Conn.	0	No Pin	No Pin
V104, 12AX7	217	84	86	Heater voltage 5.9 volts dc		217	84	86	See Pin 4 & 5
V105, 12AX7	495	217	220	Heater voltage 6.3 volts ac		500	217	220	
V202, EF-86/6267	35	0	1.2	Heater voltage 6 volts ac		50	0	1.2	-
V203, 6AW8	0.9	-	100	Heater voltage 6.3 volts ac		0.7	-	20	40
V204, OA2	150	0	Int. Conn.	0	150	Int. Conn.	0	No Pin	No Pin
V501, 6EJ7	1.3	-	1.3	Heater voltage 5.9 volts dc		0	149	93	1.3
V502, 6AW8	28	-	197			1.8	-	103	70

This chart is to be used under the following conditions: (a) RANGE switch set to 500; (b) NULL switch set to VTVM: (c) all voltage readout dials set to zero; (d) line voltage at 115/230 volts, 50 - 60 cycles; and (e) all measurements made with a VTVM from negative binding post to specified terminal.

Figure 4-4. TUBE VOLTAGE CHART

cell used in the calibration set-up to only 0.01%. However, the standard cell may be maintained to 0.002% if treated with care and not subjected to sudden temperature changes. For reasonable certainty of 0.002% cell accuracy, the certified value should be known to six places. Since the ESI voltage divider is accurate within 0.005%, the overall DC calibration system accuracy is between 0% and 0.007%.

(1) Preliminary Calibration Procedure.

(a) Set 803B meter to zero with mechanical adjustment screw on front of meter case.

(b) Set switches on 803B as follows:

RANGE	500
NULL	VTVM
AC - DC polarity	+ (positive)
all voltage readout dials	0 (zero)

(c) Set power switch to ON and allow 803B to warmup to equilibrium temperature (about 1 hour) inside its case.

(d) Set up necessary equipment to provide DC voltages of 500, 50, 5, and 0.5 volts DC with an accuracy of 0.01%. Proceed as follows: connect equipment as shown in figure 4-5; turn on all test equipment and allow it to warmup to equilibrium temperature (about 1/2 hour); set proper standard cell voltage on ESI divider; apply 500 volts DC into divider from power supply; set ESI divider to 500 and zero galvanometer by varying output of power supply while depressing coarse and then coarse and fine pushbutton switch; voltages of 500, 50 5, and 0.5 volts DC (±0.01%) are made available at output posts by merely changing position of voltage selector switch on voltage divider.

(e) Connect chassis ground binding post to line ground.

(f) On rack models, all controls may be easily reached through access holes.

(g) On cabinet models, R121, R219, and R227 may be reached through the ventilation holes. To prevent shorting control to chassis ground, use an insulated screwdriver to reach these controls. To reach calibration controls at the front of the cabinet models the instrument must be slid partly out of its cabinet.

(2) Null Detector Calibration.

(a) Perform preliminary calibration procedure as stated in paragraph 4-4c (1).

(b) Adjust null detector ZERO ADJ control R227 until meter indicates zero.

(c) Apply 500 volts DC (±0.01%) to voltmeter.

(d) Adjust VTVM GAIN ADJ control R219 for full scale deflection.

(3) 500 VDC Reference Supply Calibration.

(a) Perform preliminary calibration procedure as stated in paragraph 4-4c (1).

(b) Center CALIBRATE control at its center of rotation.

(c) Set NULL switch to 10 and voltage readout dials to 499.910.

(d) Apply 500 volts DC (±0.01%) to voltmeter.

(e) Adjust 500V ADJ control R121 for a null.

(f) Set NULL switch to 0.1 volt.

(g) Null meter by adjusting CALIBRATE control.

(h) Advance OPERATE-CALIBRATE switch against spring tension to CALIBRATE and null meter by adjusting REF CAL ADJ control R318.

(4) Range Divider Calibration.

(a) Perform preliminary calibration procedure as stated in paragraph 4-4c (1).

(b) Set switches on 803B as follows:

RANGE	50
NULL	0.01
voltage readout dials	49.9910

(c) Apply 50 volts DC (±0.01%) to voltmeter.

(d) Null 803B meter by adjusting 50 V DC ADJ control R323.

(e) Set RANGE switch to 5 volts.

(f) Apply 5 volts DC (±0.01%) in voltmeter.

(g) Null 803B meter by adjusting 5 V DC ADJ control R326.

(h) Set RANGE switch to 0.5 volts.

(i) Apply 0.5 volts DC (±0.01%) to voltmeter.

(j) Null 803B meter by adjusting 0.5 V DC ADJ control R329.

This completes the DC Differential Voltmeter calibration.

d. AC TO DC CONVERTER CALIBRATION. The DC Differential Voltmeter section of the 803B must be within specifications before the AC to DC Converter can be accurately calibrated. The AC to DC Converter must be calibrated in the following order.

(1) Preliminary Calibration Procedure.

(a) Perform DC Differential Voltmeter calibration as in paragraph 4-4c.

(b) Set switches on 803B as follows:

RANGE	500
NULL	0.01
AC-DC polarity	AC
voltage readout dials	499.910

(c) Set up the necessary equipment to provide 500, 50, 5, and 0.5 volts AC with an accuracy of at least ±0.05% at frequencies of 400 cycles and 10 kilocycles, with less than 0.1% total harmonic distortion. Proceed as follows: connect equipment as shown in figure 4-6; turn on all test equipment and allow it to warm up to equilibrium temperature (about 1/2 hour); adjust DC power supply voltage until differential voltmeter indicates RMS value of AC voltage required; apply output of DC supply to 540A and null galvanometer by adjusting internal reference supply voltage; apply output of AC oscillator to 540A and null galvanometer by adjusting AC oscillator voltage; the output of the Elin Oscillator now equals the required AC voltage.

(2) 0.5 VAC Converter Gain Adjustment.

(a) Set RANGE switch to 0.5 volt position.

(b) Apply 0.5 volts AC at 400 cycles to voltmeter.

(c) Adjust 0.5 VAC GAIN ADJ control R536 until the meter needle is within ±50 microvolts (1/2 major division) of null.

(3) 5 VAC Converter Gain Adjustment.

(a) Set RANGE switch to 5 volt position.

(b) Apply 5 volts AC at 400 cycles to voltmeter.

(c) Adjust 5 VAC GAIN ADJ control R541 for a null.


56 Ω ± 10%
VOLTMETER UNDER TEST
SPECIAL PRECISION VOLTAGE DIVIDER ESI #X194
COARSE
FINE
EPPLEY STD. CELL #100A
L & N GALVO #2430A
5.6 K ± 10%
std.
cell
in
out
G
Coarse & fine switches are momentary push button type shown in normal undepressed position. Since these switches are in the standard cell circuit they must have fine silver contacts.
MODEL 301C OR 301E

Figure 4-5. DC DIFFERENTIAL VOLTMETER CALIBRATION SET-UP



Figure 4-6. AC TO DC CONVERTER CALIBRATION SET-UP

(4) 5 VAC High Frequency Adjustment.
(a) Apply 5 volts AC at 10 kilocycles to voltmeter.
(b) Adjust 5 VAC HF TRIM control C504 for a null.

(5) 0.5 VAC High Frequency Adjustment.
(a) Set RANGE switch to 0.5 volt position.
(b) Apply 0.5 volt AC at 10 kilocycles to voltmeter.
(c) Adjust 0.5 VAC HF TRIM control C519 for a null.

(6) 500 VAC Attenuator Adjustment.
(a) Set RANGE switch to 500 volt position.
(b) Apply 500 volts AC at 400 cycles to voltmeter.
(c) Adjust 500 VAC ATTENUATOR control R534 for a null.

(7) 500 VAC High Frequency Adjustment.
(a) Apply 500 volts AC at 10 kilocycles to voltmeter.
(b) Adjust 500 VAC HF TRIM control C523 for a null.

(8) 50 VAC Attenuator Adjustment.
(a) Set RANGE switch to 50 volt position.
(b) Apply 50 volts AC at 400 cycles to voltmeter.
(c) Adjust 50 VAC ATTENUATOR control R503 for a null.

(9) 50 VAC High Frequency Adjustment.
(a) Apply 50 volts AC at 10 kilocycles to voltmeter.
(b) Adjust 50 VAC HF TRIM control C501 for a null.

This completes the AC to DC Converter calibration.

SECTION V

LIST OF REPLACEABLE PARTS

5-1. GENERAL

a. The following seven assembly lists describe all normally replaceable parts of the Model 803B, 803BR, 803B/AG, and 803BR/AG Differential AC/DC Voltmeters. Each list has a corresponding illustration on which the parts for that list are pointed out. Parts are called out on both lists and illustrations by reference designations from the schematic diagram. Those parts (mechanical) which have no reference designation are shown on the illustrations by Fluke stock number.

b. A Use Code column is provided to identify certain parts that have been added, deleted, or modified during production of the 803B. Each part for which a use code has been assigned may be identified with a particular instrument serial number by consulting the Use Code Effectivity List at the end of this section.

5-2. HOW TO OBTAIN PARTS

a. Standard components have been used whenever possible. Thus, most parts may be obtained locally. However, special components are used in some instances. All parts manufactured or altered by Fluke and all parts for which Fluke controls the design are designated by an asterisk preceding the Fluke stock number. All structural parts and special parts should be purchased from your local Fluke representative or from the factory.

b. When ordering parts always include:

(1) Reference designation, description, and Fluke stock number.

(2) Instrument model and serial number.

(3) Most structural parts are not listed. In this case, give complete description, function, and location for the part.

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Final Assembly		
	(Cabinet model, standard cell option)	*803B	
	(Rack model, standard cell option)	*803BR	
	(Cabinet model, Zener diode option)	*803B/AG	
	(Rack model, Zener diode option)	*803BR/AG	
	Front Panel Assembly (See Figure 5-2)		
	Model 803B	*138586	
	Model 803BR	*138602	
	Model 803B/AG	*138594	
	Model 803BR/AG	*138610	
	Reference Supply Board Assembly (See Figure 5-3)		
		*803B-449	E
		*803BR-412	F
		*125088	L
	Null Detector Board Assembly (See Figure 5-4)		
		*120501	Q
		*150029	R
	Range Resistor Board Assembly (See Figure 5-5)		
	Model 803B	*120477	AC
		*159541	AD
	Model 803BR	*120923	AC
		*159533	AD
	Model 803B/AG	*120972	AC
		*153478	AD
	Model 803BR/AG	*120485	AC
		*153486	AD

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Kelvin-Varley Resistor Board Assembly (See figure 5-6)	*134775	
	Converter/AC Range Switch Assembly (See figure 5-7)	*120527	
F1	Fuse, 1.5 ampere, slow-blowing (for 115 volt operation)	109231	
	Fuse, 0.75 ampere, slow-blowing (for 230 volt operation)	109256	
J4, J5	Binding post, black	101204	I
	Binding post, red	104158	J
	Binding post insulator, red (4 used)	101188	G
	Binding post insulator, dual, black (2 used)	135053	H
Q3	Transistor, germanium, PNP, special purpose, 2N301W	*116707	
R1	Resistor, variable, wirewound, 5K ±10%, 2W	111583	
R3	Resistor, precision power (803B/AG and 803BR/AG. Optimum value is selected at factory to match Zener diode. When ordering, include date and serial number listed on Range Resistor Board decal.)		
R6, R7	Resistor, wirewound, 6K ±5%, 5W	*113449	K
T1	Transformer, power	*801B-651	C
	Transformer, power	*125237	D
	Transformer, power	*149088	AG
	Transformer, power	*135012	AH
	Transformer, power	216689	AO
	Line cord, 3 wire	102822	
	Rubber foot	101253	
	Nylon foot	102921	
	Case Assembly (Cabinet model)	*120386	
	Handle, flexible black vinyl, 5-1/2" (Cabinet model)	407-101	



CABINET MODELS



RACK MODELS

Figure 5-1. FINAL ASSEMBLY

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Front Panel Assembly		
	Model 803B	*138586	
	Model 803BR	*138602	
	Model 803B/AG	*138594	
	Model 803BR/AG	*138610	
B1	Standard cell	135160	
C1	Capacitor, mylar, 0.47 uf ±10%, 600V	105494	
DS1, DS2, DS3, DS4	Lamps, decimal	102855	
	Light holder	100131	
	Light shield	101428	
	Light lens	103440	
J1, J2, J3	Binding post, black	101204	G
J2	Binding post, black	101204	H
J1, J3	Binding post, red	104158	H
	Binding post insulator, red (4 used)	101188	G
	Binding post insulator, dual, black (1 used)	135053	H
	Binding post insulator, black (2 used)	135061	H
	Binding post spacer	101212	
	Shorting link	101220	
M1	Meter, 100-0-100 microamp (M32, M49 and 111211 are interchangeable)	*M32, M49, or 111211	
R2	Resistor, variable, dual section wirewound, 1K and 100 ohm ±10%, 2W	112714	
S1	Switch, power	114850	
S2	Switch, range, DC section	*120642	
		*125138	
S3	Switch, null	*120659	
S4	Switch, operate-calibrate	*134973	
S5	Switch, AC-DC polarity	*120691	
S6	Switch, voltage dial A	*134817	
S7, S8, S9	Switch, voltage dials B, C, and D	*134841	
S10	Switch, voltage dial E	*134825	
	Knob	101287	AM
		188824	AN
		170068	AN
	Knob	101121	AM
		171660	AN
	Knob	101311	AM
		188524	AN
		170050	AN
	Knob	103614	AM
		188532	AN
		170050	AN
	Voltage dial plates (cabinet model)	*107029	
	(rack model)	*107011	
	Handle, 6" chrome plated (rack models only)	101717	



Figure 5-2. FRONT PANEL ASSEMBLY (sheet 1 of 2)



Figure 5-2. FRONT PANEL ASSEMBLY (sheet 2 of 2)

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Reference Supply Board Assembly without tubes	*803B-449 *803BR-412 *125088	E F L
C101, C102	Capacitor, electrolytic, 20 uf -10/+100%, 500V	105932	
C103	Capacitor, electrolytic, 4000 uf -10/+100%, 15V	105163	
C104	Capacitor, paper, 0.1 uf ±20%, 400V	105312	
C105	Capacitor, plastic, 0.033 uf ±20%, 600V	105916	
C106	Capacitor, plastic, 0.1 uf ±20%, 600V	105833	
C107	Capacitor, ceramic, 0.01 uf -20/+80%, 500V	105668	
CR101 thru CR103	Diode, silicon, 0.750 Amp, 600 PIV Diode, silicon, 0.750 Amp, 600 PIV	112680 112383	Y Z
CR104, CR107	Diode, silicon, 1 Amp, 50 PIV Diode, silicon, 1 Amp, 100 PIV	112409 116111	AI AJ
Q1	Transistor, germanium, NPN, 2N214 Transistor, silicon, NPN, 2N3721	116137 117267	O P
Q2	Transistor, germanium, PNP, 2N1372	116129	
R101	Resistor, composition, 1 Meg ±10%, 1/2W	108134	
R102	Resistor, composition, 220K ±10%, 1/2W	108217	
R104	Resistor, carbon film 5K ±1%, 1/2W Resistor, carbon film, 5.44K ±1%, 1/2W	107110 107235	O P
R105	Resistor, carbon film, 135K ±1%, 1/2W Resistor, carbon film, 125K ±1%, 1/2W	107201 107433	O P
R106	Resistor, composition, 8.2K ±10%, 1/2W	109017	
R107, R108	Resistor, carbon film, 50Ω ±1%, 1/2W	107037	
R109, R110	Resistor, composition, 270K ±10%, 1W	109512	
R111	Resistor, composition, 22 Meg ±10%, 1/2W	108233	
R112	Resistor, composition, 15 Meg ±10%, 1/2W	108647	
R113	Resistor, composition, 10 Meg ±10%, 1/2W	108142	
R114	Resistor, composition, 100K ±10%, 1W	109397	
R115	Resistor, wirewound, 140K ±3%, 10W	112417	
R116	Resistor, composition, 100K ±10%, 1/2W	108126	
R117	Resistor, composition, 560K ±10%, 1W	109678	
R118	Resistor, composition, 220K ±10%, 1/2W	108217	
R119	Resistor, composition, 330Ω ±10%, 1/2W	108589	
R120	Resistor, composition, 220K ±10%, 1W	109652	
R121	Resistor, variable wirewound, 5K ±5%, 2W	111609	
R122	Resistor, composition, 560K ±10%, 1W	109678	
R123	Resistor, wirewound, 386K ±0.5%, 1W	112482	
R124	Resistor, wirewound, 76K ±0.5%, 1/2W	111948	

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
R125	Resistor, composition, 82K ±10%, 1/2W	108498	
V101	Vacuum tube, pentode, EL84/6BQ5	116616	
V102	Vacuum tube, voltage reference, aged OG3	*116749	
V103	Lamp, neon glow, NE2E Lamp, neon glow, NE83	100347 170167	AK AL
V104, V105	Vacuum tube, duo triode, 12AX7	115956	



Figure 5-3. REFERENCE SUPPLY BOARD ASSEMBLY

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Null Detector Board Assembly	*120501 *150029	Q R
C201, C202	Capacitor, plastic, 0.1 uf ±20%, 200V Capacitor, plastic, 0.1 uf ±20%, 200V	106310 106435	M N
C203	Capacitor, plastic, 0.047 uf ±20%, 100V	106401	
C204	Capacitor, plastic, 0.47 uf ±20%, 200V	106419	
C205	Capacitor, electrolytic, 40 uf -10/+100%, 6V	105205	
C206	Capacitor, ceramic, 0.001 uf ±20%, 3000V	105635	
C207	Capacitor, electrolytic, 10 uf -10/+100%, 150V	106351	
C208	Capacitor, plastic, 0.1 uf ±20%, 200V Capacitor, plastic, 0.1 uf ±20%, 200V	106310 106435	M N
C209	Capacitor, plastic, 0.47 uf ±20%, 200V	106419	
C210	Capacitor, plastic, 0.1 uf ±20%, 200V Capacitor, plastic, 0.1 uf ±20%, 200V	106310 106435	M N
C211	Capacitor, plastic, 1 uf ±20%, 200V Capacitor, plastic, 0.18 uf ±10%, 200V	106450 105874	S T
C212	Capacitor, electrolytic, 200 uf -10/+100%, 6V	105189	
C213	Capacitor, ceramic, 3.3 uuf ±15%, 1000V Capacitor, ceramic, 7.5 uuf ±20%, 1000V	105577 106849	Q R
C214A, C214B	Capacitor, dual electrolytic 20/20 uf -10/+50%, 450V	106427	
C215	Capacitor, electrolytic, 15 uf -10/+150%, 6V	105700	
CR201	Diode, silicon, 0.75 Amp, 600 PIV Diode, silicon, 0.75 Amp, 600 PIV	112680 112383	Y Z
CR202, CR203	Diode, silicon, 1 Amp, 100 PIV	116111	
G1	Chopper, electronic, 60 cycle, SPDT	103051	
R201 thru R203	Resistor, composition, 1 Meg ±10%, 1/2W	108134	
R204	Resistor, composition, 3.9 Meg ±10%, 1/2W	108548	
R205	Resistor, composition, 2.7 Meg ±10%, 1/2W	108266	
R206	Resistor, composition, 470K ±10%, 1/2W	108290	
R207	Resistor, composition, 4.7K ±10%, 1/2W	108381	
R208	Resistor, composition, 10K ±10%, 1/2W	108118	
R209, R210	Resistor, composition, 1 Meg ±10%, 1/2W	108134	
R211	Resistor, composition, 330K ±10%, 1/2W	108274	
R212	Resistor, composition, 180K ±10%, 1/2W	108431	
R213	Resistor, composition, 1K ±10%, 1/2W	108563	
R214	Resistor, composition, 1 Meg ±10%, 1/2W	108134	
R215	Resistor, composition, 27K ±10%, 1/2W	108878	

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
R216	Resistor, composition, 560Ω ±10%, 1/2W	** 108316	U, AO
	Resistor, composition, 1K ±10%, 1/2W	108563	V
	Resistor, composition, 330Ω ±10%, 1/2W	** 108589	AO
R217	Resistor, composition, 100Ω ±10%, 1/2W	108100	
R218	Resistor, deposited carbon, 93.1Ω ±1%, 1/2W	107755	U
	Resistor, metal film, 90.9Ω ±1%, 1/2W	151084	V
R219	Resistor, variable wirewound, 10Ω ±20%, 1-1/4W	112672	
R220	Resistor, composition, 3.3k ±10%, 1/2W	108373	
	Resistor, composition, 2.2K ±10%, 1/2W	108605	AO
R221	Resistor, composition, 3.3K ±10%, 1/2W	108373	Q, AO
	Resistor, composition, 2.2K ±10%, 1/2W	108605	R
R222, R223	Resistor, composition, 47K ±10%, 2W	110015	
R224	Resistor, composition, 2.7Ω ±10%, 1/2W	108845	
R225, R226	Resistor, composition, 1K ±10%, 1/2W	108563	
R227	Resistor, variable, wirewound, 5K ±20%, 1-1/4W	111609	
R228, R229	Resistor, composition, 2.7K ±10%, 2W	110148	
R230	Resistor, composition, 1K ±10%, 1/2W	108563	
V201	Lamp, neon glow, type NE2E, 1/10W	100347	
V202	Vacuum tube, pentode, EF86/6267	116715	
V203	Vacuum tube, triode-pentode, 6AW8A	116434	
V204	Vacuum tube, voltage reference, OA2	115873	
	** Factory selected may be either 560 or 330 ohms		



Figure 5-4. NULL DETECTOR BOARD ASSEMBLY

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Range Resistor Board Assembly		
	Model 803B	*120477	AC
		*159541	AD
	Model 803BR	*120923	AC
		*159533	AD
	Model 803B/AG	*120972	AC
		*153478	AD
	Model 803BR/AG	*120485	AC
		*153486	AD
C301	Capacitor, plastic, 1 uf ±20%, 600V	105924	
C302	Capacitor, plastic, 2 uf ±20%, 200V	106443	
CR301	Zener diode (803B/AG and 803BR/AG. If replacement is required, CR301, R3, and R319 must be replaced with one of the Zener-resistor sets listed below. An adhesive label included must be attached to Range Resistor Board to give future ordering data for R3 and R319.)		
	Zener-resistor set 801B/G-410 (Replace with 158824)		AC
	Zener-resistor set 801B/G-407 or 801B/G-409 (These two sets are completely interchangeable.)	158824	AD
R301 thru R304	Resistors, carbon film, matched set of four, 10 Meg	200626	
R305	Resistor, carbon film, 9 Meg ±1%, 1W	107557	
R306	Resistor, carbon film, 900K ±1%, 1/2W	107391	
R307	Resistor, carbon film, 90K ±1%, 1/2W	107292	
R308	Resistor, carbon film, 9K ±1%, 1/2W	107250	
R309	Resistor, carbon film, 900 ±1%, 1/2W	107771	
R310	Resistor, carbon film, 100 ±1%, 1/2W	107730	
R311 thru R315	Resistor, composition, 22 Meg ±10%, 1/2W	108233	
R316, R317	Resistor, wirewound, 125K ±0.1%, 1W	112102	AC
	Resistor, wirewound, 112.375K ±0.05%, 1W	112110	AD
R318	Resistor, variable wirewound, 1K ±20%, 1-1/4W	111575	AE
	Resistor, variable wirewound, 3K ±20%, 1-1/4W	112458	AF
	Resistor, variable wirewound, 1K ±20%, 1-1/4W	113266	AD
R319	Resistor, wirewound, 511.7Ω ±0.1%, 1/2W	112706	AC
	Resistor, wirewound, 459.8Ω ±0.025%, 1/8W	132001	AD
	Resistor, wirewound (803B/AG and 803BR/AG. Optimum value is selected at factory to match Zener diode. When ordering, include date and serial number listed on Range Resistor Printed Circuit Board decal.)		
R320, R321	Resistor, wirewound, 112.375K ±0.05%, 1W	112110	
R322	Resistor, composition, 27K ±10%, 1W	109504	
R323	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	112433	AC
	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	113258	AD
R324	Resistor, wirewound, 28.571K ±0.05%, 1/2W	112060	
R325	Resistor, wirewound, 22.5K ±0.1%, 1/2W	112045	
R326	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	112433	AC
	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	113258	AD
R327	Resistor, wirewound, 2531.7Ω ±0.05%, 1/2W	111906	

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
R328	Resistor, wirewound, 24.75K ±0.1%, 1/2W	112052	
R329	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	112433	AC
	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	113258	AD
R330	Resistor, wirewound, 250.31Ω ±0.05%, 1/2W	112011	
R331	Resistor, composition, 270Ω ±10%, 1/2W	108241	



Figure 5-5. RANGE RESISTOR BOARD ASSEMBLY

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
	Kelvin-Varley Resistor Board Assembly	*134775	
R401 thru R406**	Resistor, wirewound, 40K ±0.02%, 1/2W	*146530	
R407 thru R417**	Resistor, wirewound, 8K ±0.005%, 1/2W	*131946	
R418 thru R428**	Resistor, wirewound, 1.6K ±0.01%, 1/8W	*131953	
R429 thru R439	Resistor, wirewound, 320Ω ±0.02%, 1/8W	*146159	
R440 thru R449	Resistor, wirewound, 64Ω ±0.1%, 1/8W	*146167	

**These resistors are factory matched for each instrument. When ordering, specify instrument model and serial number and all information stamped on resistor.



Figure 5-6. KELVIN-VARLEY RESISTOR BOARD ASSEMBLY

REFERENCE DESIGNATION	DESCRIPTIONS	FLUKE STOCK NO.	USE CODE
	Converter/AC Range Switch Assembly	*120527	
CR501, CR502	Diode, silicon, 60 ma, 40 PIV	178665	
	Converter Assembly	*120535	
C505AB	Capacitor, electrolytic, 10-10 uf -10/+50%, 500V	105130	
C506	Capacitor, ceramic, 0.005 uf ±20%, 500V	105650	
C507	Capacitor, ceramic, 300 uf ±10%, 500V	105734	
C508	Capacitor, plastic, 0.47 uf ±20%, 200V	106419	
C509	Capacitor, plastic, 0.0068 uf ±20%, 400V	106591	
C510	Capacitor, ceramic, 0.001 uf ±20%, 3000V	105635	
C511	Capacitor, plastic, 0.47 uf ±20%, 400V	105759	
C512	Capacitor, paper, 0.1 uf ±20%, 400V	105312	
C513	Capacitor, electrolytic, 20 uf -10/+100%, 50V	106229	
C514	Capacitor, ceramic, 2.2 uf -0%, 3V	106393	
C515	Capacitor, plastic, 2 uf ±20%, 200V	106443	
C516	Capacitor, paper, 1 uf ±20%, 600V	105924	
C517	Capacitor, plastic, 5 uf ±20%, 200V Capacitor, plastic, 5 uf ±5%, 200V	106468 106997	W X
C518	Capacitor, plastic, 2 uf ±20%, 200V	106443	
C522	Capacitor, electrolytic, 500 uf -10/+100%, 3V	106328	
CR503	Diode, silicon, 1 Amp, 100 PIV	116111	
R506, R507	Resistor, metal film, 68K ±5%, 2W	111112	
R508	Resistor, metal film, 56K ±5%, 2W	111104	
R509	Resistor, metal film, 100K ±5%, 5W	111195	
R510, R511	Resistor, composition, 3.3K ±10%, 1/2W	108373	
R512	Resistor, composition, 220Ω ±10%, 1/2W	108191	
R513	Resistor, composition, 270Ω ±10%, 1/2W	108241	
R514	Resistor, composition, 1.8 Meg ±10%, 1/2W	108720	
R515	Resistor, composition, 2.2 Meg ±10%, 1/2W	108225	
R516	Resistor, composition, 15 Meg ±10%, 1/2W	108647	
R517	Resistor, composition, 18 Meg ±10%, 1/2W	108985	
R518	Resistor, composition, 1.8 Meg ±10%, 1/2W	108720	

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
R519	Resistor, composition, 47Ω ±10%, 1/2W	108688	
R520	Resistor, metal film, 120K ±5%, 2W	111120	
R521	Resistor, composition, 180Ω ±10%, 1/2W	108571	
R522	Resistor, composition, 10K ±10%, 1/2W	108118	
R523	Resistor, composition, 390Ω ±10%, 1/2W	108365	
R524	Resistor, composition, 330K ±10%, 1/2W	108274	
R525	Resistor, composition, 470K ±10%, 1/2W	108290	
R526	Resistor, composition, 220K ±10%, 1/2W	108217	
R527	Resistor, composition, 47Ω ±10%, 1/2W	108688	
R528	Resistor, metal film, 150K ±5%, 2W	111138	
R529	Resistor, composition, 100K ±10%, 1W	109397	
R530	Resistor, metal film, 47K ±5%, 5W	111187	
R531	Resistor, composition, 220Ω ±10%, 1/2W	108191	
R532	Resistor, composition, 470K ±10%, 1/2W	108290	
R536	Resistor, variable wirewound, 500Ω ±10%, 1-1/4W	112433	
R537	Resistor, deposited carbon, 100K ±1%, 1/2W	107185	
R538	Resistor, wirewound, 21.6K ±0.1%, 1/2W (This is an average value, Optimum value is selected at factory.)	PR681	A
	Resistor, wirewound, 21.28K ±0.1%, 1/2W	113217	B
R539	Resistor, wirewound, 490Ω ±0.1%, 1/2W	112805	
V501	Vacuum tube, pentode, 6EJ7	116699	
V502	Vacuum tube, triode-pentode, 6AW8A	116434	
	AC Range Switch Assembly	*120543	
	AC-Range-Switch Gain Adjust Assembly		
R503	Resistor, variable wirewound, 5K ±20%, 1-1/4W	111609	A
R503	Resistor, variable wirewound, 6K ±5%, 1-1/4W	113209	B
R534	Resistor, variable wirewound, 300Ω ±20%, 1-1/4W	112870	
	AC-Range-Switch Attenuator Assembly		
C501	Capacitor, variable, air, 0.8 to 4.5 uuf, 500V	105023	
C502	Capacitor, ceramic, 20 uuf ±2%, 600V	105619	
C503	Capacitor, plastic, 0.18 uf ±10%, 600V	106740	AA
	Capacitor, plastic, 0.12 uf ±5%, 600V	107003	AB

REFERENCE DESIGNATION	DESCRIPTION	FLUKE STOCK NO.	USE CODE
C523	Capacitor, variable, air, 0.8 to 4.5 uuf, 500V	105023	
C524	Capacitor, ceramic, 300 uuf ±5%, 600V	105601	
C525	Capacitor, ceramic, 82 uuf ±5%, 600V	105940	
R501	Resistor, metal film, 1 Meg ±1%, 1/2W	111146	
R502	Resistor, metal film, 122K ±1%, 1/2W	111260	
R533	Resistor, metal film, 500K ±1%, 1/2W	111153	
R535	Resistor, wirewound, 10.05K ±0.1%, 1/2W	112813	
R543	Resistor, metal film, 500K ±1%, 1/2W	111153	
R544	Resistor, composition, 390K ±10%, 1/2W	108993	
	AC-Range-Switch Gain Network Assembly		
C504, C519	Capacitor, variable, air, 0.8 to 4.5 uuf, 500V	105023	
C520	Capacitor, ceramic, 3.3 uuf ±20%, 600V	106583	
C521	Capacitor, ceramic, 82 uuf ±2%, 600V	105940	
R504	Resistor, metal film, 1 Meg ±0.5%, 1/2W	111252	
R505	Resistor, composition, 47Ω ±10%, 1/2W	108688	
R540	Resistor, metal film, 500K ±0.5%, 1/2W	111245	
R541	Resistor, variable wirewound, 1K ±10%, 1/4W Resistor, variable wirewound, 2K ±10%, 1/4W	112698 113191	A B
R542	Resistor, metal film, 48.75K ±1%, 1/2W	111443	
	AC-Range-Switch Switch Assembly		
S2	Switch, range, AC section	*120683	



Figure 5-7. CONVERTER/AC RANGE SWITCH ASSEMBLY (sheet 1 of 2)



Figure 5-7. CONVERTER/AC RANGE SWITCH ASSEMBLY (sheet 2 of 2)

USE CODE EFFECTIVITY

The following list of use codes is intended to allow the customer to determine the effectivity of all replaceable parts. All parts with no code are used on all instruments with serial numbers above 123. New codes will be added as necessary on forthcoming instruments.

USE CODE	EFFECTIVITY
No Code	Model 803B serial number 123 and on Model 803BR serial number 123 and on Model 803B/AG serial number 123 and on Model 803BR/AG serial number 123 and on
A	Model 803B serial number 123 thru 731 Model 803BR serial number 123 thru 306 Model 803B/AG serial number 123 thru 731 Model 803BR/AG serial number 123 thru 306
B	Model 803B serial number 732 and on Model 803BR serial number 307 and on Model 803B/AG serial number 732 and on Model 803BR/AG serial number 307 and on
C	Model 803B serial number 123 thru 1386 Model 803BR serial number 123 thru 431 Model 803B/AG serial number 123 thru 1386 Model 803BR/AG serial number 123 thru 431
D	Model 803B serial number 1387 thru 2616 Model 803BR serial number 432 thru 851 Model 803B/AG serial number 1387 thru 2616 Model 803BR/AG serial number 432 thru 851
E	Model 803B serial number 123 thru 1771 Model 803BR serial number 432 thru 531 Model 803B/AG serial number 123 thru 1771 Model 803BR/AG serial number 432 thru 531
F	Model 803BR serial number 123 thru 431 Model 803BR/AG serial number 123 thru 431
G	Model 803B serial number 123 thru 1046 Model 803BR serial number 123 thru 406 Model 803B/AG serial number 123 thru 1046 Model 803BR/AG serial number 123 thru 406
H	Model 803B serial number 1047 and on Model 803BR serial number 407 and on Model 803B/AG serial number 1047 and on Model 803BR/AG serial number 407 and on
I	Model 803B serial number 123 thru 1386 Model 803BR serial number 123 thru 431 Model 803B/AG serial number 123 thru 1386 Model 803BR/AG serial number 123 thru 431
J	Model 803B serial number 1387 and on Model 803BR serial number 432 and on Model 803B/AG serial number 1387 and on Model 803BR/AG serial number 432 and on
K	Model 803B serial number 1563 and on Model 803BR serial number 532 and on Model 803B/AG serial number 1563 and on Model 803BR/AG serial number 532 and on
L	Model 803B serial number 1772 and on Model 803BR serial number 532 and on Model 803B/AG serial number 1772 and on Model 803BR/AG serial number 532 and on
M	Model 803B serial number 123 thru 2269 Model 803BR serial number 123 thru 666 Model 803B/AG serial number 123 thru 2269 Model 803BR/AG serial number 123 thru 666
N	Model 803B serial number 2270 and on Model 803BR serial number 667 and on Model 803B/AG serial number 2270 and on Model 803BR/AG serial number 667 and on
O	Model 803B serial number 123 thru 2530 Model 803BR serial number 123 thru 776 Model 803B/AG serial number 123 thru 2530 Model 803BR/AG serial number 123 thru 776
P	Model 803B serial number 2531 and on Model 803BR serial number 777 and on Model 803B/AG serial number 2531 and on Model 803BR/AG serial number 777 and on
Q	Model 803B serial number 123 thru 2616 Model 803BR serial number 123 thru 851 Model 803B/AG serial number 123 thru 2616 Model 803BR/AG serial number 123 thru 851
R	Model 803B serial number 2617 and on Model 803BR serial number 852 and on Model 803B/AG serial number 2617 and on Model 803BR/AG serial number 852 and on
S	Model 803B serial number 123 thru 2616 and 3026 and on Model 803BR serial number 123 thru 851 and 882 and on Model 803B/AG serial number 123 thru 2616 and 3026 and on Model 803BR/AG serial number 123 thru 851 and 882 and on
T	Model 803B serial number 2617 thru 3025 Model 803BR serial number 852 thru 881 Model 803B/AG serial number 2617 thru 3025 Model 803BR/AG serial number 852 thru 881
U	Model 803B serial number 123 thru 3025 Model 803BR serial number 123 thru 881 Model 803B/AG serial number 123 thru 3025 Model 803BR/AG serial number 123 thru 881
V	Model 803B serial number 3026 and on Model 803BR serial number 882 and on Model 803B/AG serial number 3026 and on Model 803BR/AG serial number 882 and on
W	Model 803B serial number 123 thru 2301 Model 803BR serial number 123 thru 666 Model 803B/AG serial number 123 thru 2301 Model 803BR/AG serial number 123 thru 666
X	Model 803B serial number 2302 and on Model 803BR serial number 667 and on Model 803B/AG serial number 2302 and on Model 803BR/AG serial number 667 and on

USE CODE	EFFECTIVITY
Y	Model 803B serial number 123 thru 3016 Model 803BR serial number 123 thru 881 Model 803B/AG serial number 123 thru 3016 Model 803BR/AG serial number 123 thru 881
Z	Model 803B serial number 3017 and on Model 803BR serial number 882 and on Model 803B/AG serial number 3017 and on Model 803BR/AG serial number 882 and on
AA	Model 803B serial number 123 thru 3566 Model 803BR serial number 123 thru 976 Model 803B/AG serial number 123 thru 3566 Model 803BR/AG serial number 123 thru 976
AB	Model 803B serial number 3567 and on Model 803BR serial number 977 and on Model 803B/AG serial number 3567 and on Model 803BR/AG serial number 977 and on
AC	Model 803B serial number 123 thru 3604 Model 803BR serial number 123 thru 1022 Model 803B/AG serial number 123 thru 3077 Model 803BR/AG serial number 123 thru 986
AD	Model 803B serial number 3605 and on Model 803BR serial number 1023 and on Model 803B/AG serial number 3078 and on Model 803BR/AG serial number 987 and on
AE	Model 803B serial number 123 thru 3604 Model 803BR serial number 123 thru 1022
AF	Model 803B/AG serial number 123 thru 3077 Model 803BR/AG serial number 123 thru 986
AG	Model 803B serial number 2617 thru 3944 Model 803BR serial number 852 thru 1091 Model 803B/AG serial number 2617 thru 3944 Model 803BR/AG serial number 852 thru 1091
AH	Model 803B serial number 3945 and on Model 803BR serial number 1092 and on Model 803B/AG serial number 3945 and on Model 803BR/AG serial number 1092 and on
AI	Model 803B serial number 123 thru 3995 Model 803BR serial number 123 thru 1116 Model 803B/AG serial number 123 thru 3995 Model 803BR/AG serial number 123 thru 1116
AJ	Model 803B serial number 3996 and on Model 803BR serial number 1117 and on Model 803B/AG serial number 3996 and on Model 803BR/AG serial number 1117 and on
AK	Model 803B serial number 123 thru 4115 Model 803BR serial number 123 thru 1141 Model 803B/AG serial number 123 thru 4115 Model 803BR/AG serial number 123 thru 1141
AL	Model 803B serial number 4116 and on Model 803BR serial number 1142 and on Model 803B/AG serial number 4116 and on Model 803BR/AG serial number 1142 and on
AM	Model 803B serial number 123 thru 4446 Model 803BR serial number 123 thru 1166 Model 803B/AG serial number 123 thru 4446 Model 803BR/AG serial number 123 thru 1166
AN	Model 803B serial number 4447 and on Model 803BR serial number 1167 and on Model 803B/AG serial number 4447 and on Model 803BR/AG serial number 1167 and on
AO	Model 803B serial number 5693 and on Model 803BR serial number 1437 and on
AP	Model 803B serial number 5693 and on Model 803B serial number 1115 and on
AQ	Model 803B serial number 5803 and on Model 803BR serial number 1511 and on Model 803B/AG serial number 5693 and on Model 803BR/AG serial number 1115 and on

SECTION VI

ACCESSORIES

6-1. PRECISION VOLTAGE DIVIDERS

6-2. The FLUKE 80A, 80D, and 80E Voltage Dividers provide the FLUKE 800 Series Differential Voltmeters with the ability to make high accuracy measurements up to 30,000 volts DC. All models contain a zero center panel meter which allows the polarity and approximate magnitude of the unknown high voltage to be easily observed. At maximum input, all units draw but 1 ma of current from the unknown. The extreme accuracy and excellent long term stability of these dividers are obtained by using properly aged precision wirewound resistors which have a very low temperature coefficient. To further ensure high accuracy and long term stability at very high voltages, the 80D dividers have all resistance components immersed in oil within a hermetically sealed container. As an additional feature, all 80D and 80E models are provided with a 1 volt tap which allows measurements of high voltages with a laboratory potentiometer. Specifications for the standard models are shown on next page. Other intermediate models are available upon special request.



MODEL 80A

MODEL 80D



MODEL 80E

Model No.	Maximum Input Voltage	Total Resistance	Current Drawn At Max. Input	Division Ratio			Division Ratio Accuracy	Stability of Division Accuracy Per Year
				500V Out	10V Out	1V Out		
80A-1	1 KV	1 M	1 ma	2:1	——	——	±0.015%	——
80A-2	2 KV	2 M	1 ma	4:1	——	——	±0.015%	——
80E-5	5 KV	5 M	1 ma	—	500:1	5,000:1	±0.01%	±0.01%
80E-10	10 KV	10 M	1 ma	—	1000:1	10,000:1	±0.01%	±0.01%
80D-30	30 KV	30 M	1 ma	60:1	3000:1	30,000:1	±0.01%	±0.01%

MODELS	SIZE	INPUT CONNECTOR	OUTPUT CONNECTOR
80A	6-3/4" high 5-1/4" wide 2-1/4" deep	UG-560U with mating connector supplied	Insulated binding posts on 3/4" centers
80E	7" high 8-1/2" wide 8" deep	MS3102A-18-165 with mating connector supplied	Insulated binding posts on 3/4" centers for both outputs
80D	13" high 9-3/4" wide 16" deep	Special 5" ceramic standoff with mating 6" guard supplied	Insulated binding post on 3/4" centers for both outputs

MODEL A88 ISOLATION AMPLIFIER

6-3. ISOLATION AMPLIFIER

6-4. The FLUKE Model A88 all solid-state isolation amplifier is designed to provide isolation between the output of a differential voltmeter and the input of a recorder. Thus, the A88 will allow the use of a wide range of strip chart recorders for recording the voltmeter reading without regard to the input isolation characteristics of the recorder. The A88 is also excellent for making accurate dc microvolt and nanoampere measurements in the presents of common mode voltages up to 1100 vdc and 3 vac, 50 to 500 cycles.

GAIN: 1 volt output per microampere input.

GAIN ACCURACY: ±2%.

INPUT CURRENT RANGE: 0 to 2 microamperes.

INPUT VOLTAGE RANGE: 0 to 2 millivolts nominal.

INPUT RESISTANCE: 950 ohms (±5%).

OUTPUT VOLTAGE RANGE: 0 to 2 volts open circuit.

OUTPUT RESISTANCE: 1000 ohms (±5%).

INPUT ISOLATION FROM CHASSES: Greater than 5×10^{11} ohms at 25°C (77°F), 60% RH and 1×10^{10} ohms at 50°C (122°F), 80% RH.

APPENDIX A

FEDERAL SUPPLY CODE FOR MANUFACTURERS

A-1. CODE TO NAME

A-2. The following five-digit code numbers are listed in numerical sequence along with the manufacturer's name and address to which the code has been assigned. The Federal Supply Code has been taken from Cataloging Handbook H 4-2, Code to Name.

00213	Sage Electronics Corp. Rochester, New York
00327	Welwyn International, Inc. Westlake, Ohio
00656	Aerovox Corp. New Bedford, Massachusetts
00779	AMP Inc. Harrisberg, Pennsylvania
01121	Allen-Bradley Co. Milwaukee, Wisconsin
01281	TRW Semiconductors Lawndale, California
01295	Texas Instruments, Inc. Semiconductor Components Div. Dallas, Texas
01686	RCL Electronics Inc. Manchester, New Hampshire
01730	Deleted
01884	Dearborn Electronics Inc. Orlando, Florida
02114	Ferroxcube Corp. Saugerties, New York
02606	Replaced by 15801
02660	Amphenol-Borg Elect. Corp. Broadview, Illinois
02799	Arco Capacitors, Inc. Los Angeles, California
03614	Replaced by 71400
03651	Replaced by 44655
03797	Eldema Corp. Compton, California
03877	Transitron Electronic Corp. Wakefield, Massachusetts
03888	Pyrofilm Resistor Co., Inc. Cedar Knolls, New Jersey
03911	Clairex Corp. New York, New York
03980	Muirhead Instruments, Inc. Mountainside, New Jersey
04009	Arrow Hart and Hegemen Electronic Company Hartford, Connecticut
04062	Replaced by 72136
04202	Replaced by 81312
04217	Essex Wire Corp Wire & Cable Div. Anaheim, California
04221	Aemco Div. of Midtex Inc. Mankato, Minnesota
04645	Replaced by 75376
04713	Motorola Semiconductor Products Inc. Phoenix, Arizona
05082	Replaced by 94154
05236	Jonathan Mfg. Co. Fullerton, California
05277	Westinghouse Electric Corp. Semiconductor Dept. Youngwood, Pennsylvania
05278	Replaced by 43543
05397	Union Carbide Corp. Electronics Div. Cleveland, Ohio
05571	Sprague Electric Co Pacific Div. Los Angeles, California
05704	Alac, Inc. Glendale, California
05820	Wakefield Engineering Ind. Wakefield, Massachusetts
06001	General Electric Company Capacitor Department Irmo, South Carolina
06136	Replaced by 63743
06473	Amphenol Space & Missile Sys. Chatsworth, California
06555	Beede Electrical Instrument Co. Penacook, New Hampshire
06739	Electron Corp. Littletown, Colorado
06743	Clevite Corp. Cleveland, Ohio
06751	Semcor Div. Components Phoenix, Arizona
06860	Gould National Batteries Inc. City of Industry, California
06980	Eitel-McCullough, Inc. San Carlos, California
07115	Replaced by 14674
07138	Westinghouse Electric Corp Electronic Tube Div. Elmira, New York
07263	Fairchild Semiconductor Div. of Fairchild Camera & Instrument Corp. Mountain View, California
07344	Bircher Co., Inc. Rochester, New York
07792	Lerma Engineering Corp Northampton, Massachusetts
07910	Continental Device Corp. Hawthorne, California
08530	Reliance Mica Corp. Brooklyn, New York
08792	CBS Electronics Semiconductor Operations-Div. of CBS Inc. Lowell, Massachusetts
08806	General Electric Co. Miniature Lamp Dept. Cleveland, Ohio
08863	Nylomatic Corp. Norrisville, Pennsylvania
08988	Skottie Electronics Inc. Archbald, Pennsylvania
09922	Burndy Corp. Norwalk, Connecticut
11237	Chicago Telephone of Calif. Inc. South Pasadena, California
11358	CBS Electronics Div. of CBS Inc. Newburyport, Massachusetts
11403	Best Products Co. Chicago, Illinois
11503	Keystone Mfg Div. of Avis Industrial Corp. Warren, Michigan
12014	Chicago Rivet & Machine Co. Bellwood, Illinois
12040	National Semiconductor Corp. Danburry, Connecticut
12060	Diodes, Inc. Chatsworth, California
12136	Philadelphia Handle Co. Camden, New Jersey
12323	Presin Co., Inc. Shelton, Connecticut
12327	Freeway Washer & Stamping Co. Cleveland, Ohio
12400	Replaced by 75042
12617	Hamlin Inc. Lake Mills, Wisconsin
12697	Clarostat Mfg. Co. Dover, New Hampshire
12749	James Electronics Chicago, Illinois

12856 Micrometals
Sierra Madre, California

12954 Dickson Electronics Corp.
Scottsdale, Arizona

13606 Sprague Electric Co.
Transistor Div.
Concord, New Hampshire

13839 Replaced by 23732

14099 Semtech Corp.
Newbury Park, California

14193 California Resistor Corp.
Santa Monica, California

14298 American Components, Inc.
Conshohocken, Pennsylvania

14655 Cornell-Dubilier Electronics
Newark, New Jersey

14674 Corning Glass Works
Corning, New York

14752 Electro Cube Inc.
San Gabriel, California

14869 Replaced by 96853

15636 Elec-Trol Inc.
Northridge, California

15801 Fenwal Electronics Inc.
Framingham, Massachusetts

15818 Amelco Semiconductor
Div. of Teledyne Inc.
Mountain View, California

15849 Useco, Inc.
Mt. Vernon, New York

15909 Replaced by 17870

16332 Replaced by 28478

16473 Cambridge Scientific Ind. Inc.
Cambridge, Maryland

16742 Paramount Plastics
Downey, California

16758 Delco Radio
Div. of General Motors
Kokomo, Indiana

17069 Circuit Structures Lab.
Upland, California

17856 Siliconix, Inc.
Sunnyvale, California

17870 Daven-Div. of Thomas A. Edison
Ind. --McGraw-Edison Co.
Manchester, New Hampshire

18083 Deleted

18178 Vactec Inc.
Maryland Heights, Missouri

18736 Voltronics Corp.
Hanover, New Jersey

19429 Montronics, Inc.
Seattle, Washington

19451 Perine Machinery & Supply Co.
Seattle, Washington

19701 Electra Mfg. Co.
Independence, Kansas

20584 Enochs Mfg. Co.
Indianapolis, Indiana

22767 ITT Semiconductors
Div. of ITT
Palo Alto, California

23732 Tracor
Rockville, Maryland

24248 Southco
Div. of South Chester Corp.
Lester, Pennsylvania

24655 General Radio Co.
West Concord, Massachusetts

25403 Amperex Electronic Corp
Semiconductor & Receiving
Tube Division
Slatersville, Rhode Island

28478 Deltrol Controls Corp.
Milwaukee, Wisconsin

28520 Heyman Mfg. Co.
Kenilworth, New Jersey

30323 Illinois Tool Works Inc.
Chicago, Illinois

33173 General Electric Co.
Tube Dept.
Owensboro, Kentucky

37942 Mallory, P. R., & Co., Inc.
Indianapolis, Indiana

38315 Honeywell Inc.
Precision Meter Div.
Manchester, New Hampshire

42498 National Company
Melrose, Massachusetts

43543 Nytronics Inc.
Transformer Co. Div.
Alpha, New Jersey

44655 Ohmite Mfg. Co.
Skokie, Illinois

49671 Radio Corp. of America
New York, New York

49956 Raytheon Company
Lexington, Maine

53021 Sangamo Electric Co.
Springfield, Illinois

55026 Simpson Electric Company
Chicago, Illinois

56289 Sprague Electric Co.
North Adams, Massachusetts

58474 Superior Electric Co.
Bristol, Connecticut

60399 Torrington Mfg. Co.
Torrington, Connecticut

62460 Deleted

63743 Ward Leonard Electric Co.
Mount Vernon, New York

64834 West Mfg. Co.
San Francisco, California

65092 Weston Instruments Inc.
Newark, New Jersey

66150 Winslow Tele-Tronics Inc.
Asbury Park, New Jersey

70563 Amperite Company
Union City, New Jersey

70903 Belden Mfg. Co.
Chicago, Illinois

71002 Birnbach Radio Co., Inc.
New York, New York

71400 Bussmann Mfg.
Div. of McGraw-Edison Co.
St. Louis, Missouri

71450 CTS Corp.
Elkhart, Indiana

71468 ITT Cannon Electric Inc.
Los Angeles, California

71482 Clare, C P. & Co.
Chicago, Illinois

71590 Centralab
Div. of Globe Union Inc.
Milwaukee, Wisconsin

71707 Coto Coil Co., Inc.
Providence, Rhode Island

71744 Chicago Miniature Lamp Works
Chicago, Illinois

71785 Cinch Mfg. Co. & Howard
B. Jones Div.
Chicago, Illinois

72005 Driver, Wilber B., Co.
Newark, New Jersey

72092 Replaced by 06980

72136 Electro Motive Mfg. Co.
Willimantic, Connecticut

72259 Nytronics Inc.
Berkeley Heights, New Jersey

72354 Deleted

72619 Dialight Corp
Brooklyn, New York

72653 G. C. Electronics
Rockford, Illinois

72665 Replaced by 90303

72794 Dzus Fastener Co., Inc.
West Islip, New York

72928 Gudeman Co.
Chicago, Illinois

72982 Erie Tech. Products Inc.
Erie, Pennsylvania

73138 Beckman Instruments Inc.
Helipot Division
Fullerton, California

73293 Hughes Aircraft Co.
Electron Dynamics Div.
Newport Beach, California

73445 Amperex Electronic Corp.
Hicksville, New York

73559 Carling Electric Inc.
Hartford, Connecticut

73586 Circle F Industries
Trenton, New Jersey

73734 Federal Screw Products, Inc.
Chicago, Illinois

73743 Fischer Special Mfg. Co.
Cincinnati, Ohio

73899 JFD Electronics Co.
Brooklyn, New York

73949 Guardian Electric Mfg. Co.
Chicago, Illinois

74199 Quam Nichols Co.
Chicago, Illinois

74217 Radio Switch Corp.
Marlboro, New Jersey

74276 Signalite Inc.
Neptune, New Jersey

74306 Piezo Crystal Co.
Carlisle, Pennsylvania

74542 Hoyt Elect. Instr. Works
Penacook, New Hampshire

74970 Johnson, E. F., Co.
Waseca, Minnesota

75042 IRC Inc.
Philadelphia, Pennsylvania

75376 Kurz-Kasch, Inc.
Dayton, Ohio

75382 Kulka Electric Corp.
Mt. Vernon, New York

75915 Littlefuse Inc.
Des Plaines, Illinois

76854 Oak Mfg. Co.
Crystal Lake, Illinois

77342 Potter & Brumfield
Div. of Amer. Machine & Foundry
Princeton, Indiana

77969 Rubbercraft Corp. of Calif. LTD.
Torrance, California

78189 Shakeproof
Div. of Illinois Tool Works
Elgin, Illinois

78277 Sigma Instruments, Inc.
South Braintree, Massachusetts

78488 Stackpole Carbon Co.
St. Marys, Pennsylvania

78553 Tinnerman Products
Cleveland, Ohio

79136 Waldes Kohinoor Inc.
Long Island City, New York

79497 Western Rubber Company
Goshen, Indiana

79963 Zierick Mfg. Corp.
New Rochelle, New York

80031 Mepco
Div. of Sessions Clock Co.
Morristown, New Jersey

80145 API Instruments Co.
Chesterland, Ohio

80183 Sprague Products
North Adams, Massachusetts

80294 Bourns Inc.
Riverside, California

80583 Hammarlund Co., Inc.
Mars Hill, North Carolina

80640 Stevens, Arnold Inc.
Boston, Massachusetts

81073 Grayhill Inc.
La Grange, Illinois

81312 Winchester Electronics
Div. of Litton Industries
Oakville, Connecticut

81439 Therm-O-Disc Inc.
Mansfield, Ohio

81483 International Rectifier Corp.
El Segundo, California

81590 Korry Mfg. Co.
Seattle, Washington

82376 Deleted

82389 Switchcraft Inc.
Chicago, Illinois

82415 Price Electric Corp.
Frederick, Maryland

82872 Roanwell Corp.
New York, New York

82877 Rotron Mfg. Co., Inc.
Woodstock, New York

82879 ITT Wire & Cable Div.
Pawtucket, Rhode Island

83003 Varo Inc.
Garland, Texas

83298 Bendix Corp.
Electric Power Division
Eatontown, New Jersey

83330 Smith, Herman H., Inc.
Brooklyn, New York

83478 Rubbercraft Corp. of America
New Haven, Connecticut

83594 Burroughs Corp.
Electronic Components Div.
Plainfield, New Jersey

83740 Union Carbide Corp.
Consumer Products Div.
New York, New York

84171 Arco Electronics, Inc.
Great Neck, New York

84411 TRW
Ogallala, Nebraska

86577 Precision Metal Products
Stoneham, Massachusetts

86684 Radio Corp. of America
Electronic Components & Devices
Harrison, New Jersey

86689 Deleted

87034 Marco-Oak Inc.
Anaheim, California

88419 Use 14655

88690 Replaced by 04217

89536 Fluke, John Mfg. Co., Inc.
Seattle, Washington

89730 Replaced by 08806

90201 Mallory Capacitor Co.
Indianapolis, Indiana

90215 Best Stamp & Mfg. Co.
Kansas City, Missouri

90211 Square D Co.
Chicago, Illinois

90303 Mallory Battery Co.
Tarrytown, New York

91293 Johanson Mfg. Co.
Boonton, New Jersey

91407 Replaced by 58474

91637 Dale Electronics Inc.
Columbus, Nebraska

91662 Elco Corp.
Willow Grove, Pennsylvania

91737 Gremar Mfg. Co., Inc.
Wakefield, Massachusetts

91802 Industrial Devices, Inc.
Edgewater, New Jersey

91836 King's Electronics
Tuckahoe, New York

91929 Honeywell Inc.
Micro Switch Div.
Freeport, Illinois

91934 Miller Electric Co., Inc.
Pawtucket, Rhode Island

93332 Sylvania Electric Products
Semiconductor Products Div.
Woburn, Massachusetts

94145 Replaced by 49956

94154 Tung-Sol
Div. of Wagner Electric Corp.
Newark, New Jersey

95146 Alco Electronics Products Inc.
Lawrence, Massachusetts

95263 Leecraft Mfg. Co.
Long Island City, New York

95264 Replaced by 98278

95275 Vitramon Inc.
Bridgeport, Connecticut

95303 Radio Corp. of America
Solid State & Receiving Tube Div.
Cincinnati, Ohio

95354 Methode Mfg. Corp.
Rolling Meadows, Illinois

95712 Dage Electric Co., Inc.
Franklin, Indiana

95987 Weckesser Co., Inc.
Chicago, Illinois

96733 San Fernando Electric Mfg. Co.
San Fernando, California

96853 Rustrak Instrument Co.
Manchester, New Hampshire

96881 Thomson Industries, Inc.
Manhasset, New York

97540 Master Mobile Mounts
Div. of Whitehall Electronics Corp.
Los Angeles, California

97913 Industrial Electronic Hdware Corp.
New York, New York

97945 White, S. S. Co.
Plastics Div.
New York, New York

97966 Replaced by 11358

98094 Replaced by 49956

98278 Microdot Inc.
Pasadena, California

98291 Sealectro Corp.
Conhex Div
Mamaroneck, New York

98388 Accurate Rubber & Plastics
Culver City, California

98743 Replaced by 12749

98925 Deleted

99120 Plastic Capacitors, Inc.
Chicago, Illinois

99217 Southern Electronics Corp.
Burbank, California

99515 Marshall Industries
Capacitor Div.
Monrovia, California

Revised August 1, 1968
Using H4-1 and H4-2
Dated June , 1968

WARRANTY

The JOHN FLUKE MFG. CO., INC. warrants each instrument manufactured by them to be free from defects in material and workmanship. Their obligation under this Warranty is limited to servicing or adjusting an instrument returned to the factory for that purpose, and to making good at the factory any part or parts thereof; except tubes, fuses, choppers and batteries, which shall, within one year after making delivery to the original purchaser, be returned by the original purchaser with transportation charges prepaid, and which upon their examination shall disclose to their satisfaction to have been thus defective. If the fault has been caused by misuse or abnormal conditions of operation, repairs will be billed at a nominal cost. In this case, an estimate will be submitted before work is started, if requested.

If any fault develops, the following steps should be taken.

1. Notify the John Fluke Mfg. Co., Inc., giving full details of the difficulty, and include the Model number, type number, and serial number. On receipt of this information, service data or shipping instructions will be forwarded to you.

2. On receipt of the shipping instructions, forward the instrument prepaid, and repairs will be made at the factory. If requested, an estimate of the charges will be made before the work begins, provided the instrument is not covered by the Warranty.

SHIPPING

All shipments of John Fluke Mfg. Co., Inc. instruments should be made via Railway Express prepaid. The instrument should be shipped in the original packing carton; or if it is not available, use any suitable container that is rigid. If a substitute container is used, the instrument should be wrapped in paper and surrounded with at least four inches of excelsior or similar shock-absorbing material.

CLAIM FOR DAMAGE IN SHIPMENT

The instrument should be thoroughly inspected immediately upon receipt. All material in the container should be checked against the enclosed packing list. The manufacturer will not be responsible for shortages against the packing sheet unless notified immediately. If the instrument fails to operate properly, or is damaged in any way, a claim should be filed with the carrier. A full report of the damage should be obtained by the claim agent, and this report should be forwarded to John Fluke Mfg. Co., Inc. Upon receipt of this report you will be advised of the disposition of the equipment for repair or replacement. Include the model number, type number, and serial number when referring to this instrument for any reason.

The John Fluke Mfg. Co., Inc. will be happy to answer all application questions which will enhance your use of this instrument. Please address your requests to:

JOHN FLUKE MFG. CO., INC., P. O. BOX 7428, SEATTLE 33, WASHINGTON

Sales and Service Representatives

ALABAMA

HUNTSVILLE
BCS Associates, Inc.
2317 Bob Wallace Ave. S.W.
Tel. (205) 534-1648

ALASKA

SEATTLE
Instrument Specialists, Inc.
5950 Sixth Ave. South
Suite 106
Seattle, Washington
Tel. (206) 767-4260

ARIZONA

PHOENIX
Barnhill Associates
4900 E. Indian School Road
Tel. (602) 959-2115

CALIFORNIA

LOS ANGELES
Instrument Specialists, Inc.
2870 Los Feliz Place
Tel. (213) 665-5181

SAN FRANCISCO
Instrument Specialists, Inc.
2359 De La Cruz
Santa Clara, California
Tel. (408) 244-1505

COLORADO

DENVER
Barnhill Associates
1170 S. Sheridan Blvd.
Tel (303) 934-5505

CONNECTICUT

HARTFORD
Instrument Representatives, Inc.
P.O. Box 165
Glastonbury, Connecticut
Tel. (203) 633-0777

FLORIDA

ORLANDO
BCS Associates, Inc.
940 N. Fern Creek Ave.
Tel. (305) 425-2764

HAWAII

HONOLULU
Industrial Electronics, Inc.
646 Queen Street
Tel. (808) 506-095

ILLINOIS

CHICAGO
Cozzens & Cudahy, Inc.
9501 W. Devon Ave.
Rosemont, Illinois
Tel. (312) 825-1144

INDIANA

INDIANAPOLIS
Cozzens & Cudahy, Inc.
44 Kirk Drive
Tel. (317) 244-2456

LOUISIANA

NEW ORLEANS
BCS Associates, Inc.
P.O. Box 7371
Metairie, Louisiana
Tel. (504) 888-2266

MARYLAND

BALTIMORE
Electronic Marketing Assoc.
11501 Huff Court
Kensington, Maryland
Tel. (301) 744-7700

MASSACHUSETTS

BOSTON
Instrument Representatives, Inc.
1046 Massachusetts Avenue
Arlington, Massachusetts
Tel. (617) 646-1034

MICHIGAN

DETROIT
Technitron, Inc.
13657 Grand River Ave.
Tel. (313) 838-7324

MINNESOTA

MINNEAPOLIS
Cozzens & Cudahy, Inc.
7710 Computer Ave.
Tel. (612) 920-1022

MISSOURI

ST. LOUIS
Cozzens & Cudahy, Inc.
10534 Natural Bridge Road
Edmundson, Missouri
Tel. (314) 423-1234

NEW JERSEY

NEWARK
SBM Associates, Inc.
1519 Stuyvesant Avenue
Union, New Jersey
Tel. (201) 687-8737

NEW MEXICO

ALBUQUERQUE
Barnhill Associates
827 Pennsylvania Ave.
Tel. (505) 265-7766

NEW YORK

NEW YORK
SBM Associates, Inc.
28 Hobby Street
Pleasantville, New York
Tel. (914) 769-1811

LONG ISLAND
SBM Associates, Inc.
528 Old Country Road
Plainview, Long Island
Tel. (516) 433-1421

ROCHESTER
SBM Associates, Inc.
800 Linden Avenue
Tel. (716) 381-8330

SYRACUSE
SBM Associates, Inc.
138 Pickard Bldg.
5858 E. Molloy Road
Tel. (315) 454-9377

NORTH CAROLINA

GREENSBORO
BCS Associates, Inc.
1039 E. Wendover Avenue
Tel. (919) 273-1918

OHIO

CLEVELAND
Technitron, Inc.
23203 Lorain Road
North Olmsted, Ohio
Tel. (216) 734-0960

DAYTON
Technitron, Inc.
1250 W. Dorothy Lane
Tel. (513) 298-9964

OREGON

PORTLAND
Instrument Specialists, Inc.
5950 Sixth Ave. South
Suite 106
Seattle, Washington
Tel. (206) 767-4260

PENNSYLVANIA

PHILADELPHIA
Acromatix Associates, Inc.
3118 Germantown Pike
Fairview Village, Pennsylvania
Tel. (215) 279-0377

PITTSBURGH
Technitron, Inc.
114 Spring Grove Road
Tel. (412) 371-1231

TEXAS

DALLAS
Barnhill Associates
507B Bishop Street
Richardson, Texas
Tel. (214) AD 1-2573

HOUSTON
Barnhill Associates
Suite 203
3810 Westheimer
Tel. (713) NA 1-0040

WASHINGTON

SEATTLE
Instrument Specialists, Inc.
5950 Sixth Ave. South
Suite 106
Seattle, Washington
Tel. (206) 767-4260

WASHINGTON, D.C.

Electronic Marketing Associates
11501 Huff Court
Kensington, Maryland
Tel. (301) 946-0300

CANADA

BRITISH COLUMBIA

VANCOUVER
Allan Crawford Associates, Ltd.
5901 East Broadway
North Burnaby 2, B.C.
Tel. (604) 291-7161

ONTARIO

OTTAWA
Allan Crawford Associates, Ltd.
376 Churchill Avenue — Suite 106
Tel. (613) 725-1288

TORONTO
Allan Crawford Associates, Ltd.
65 Martin Ross Avenue
Downsview, Ontario
Tel. (416) 636-4910

QUEBEC

MONTREAL
Allan Crawford Associates, Ltd.
6999 Cote de Neiges Road
Tel. (514) 739-6776

International Representatives

AUSTRALIA

Elmesco Instruments
41 Carter Road
Brookvale, N.S.W., Australia

AUSTRIA

Omni Ray AG
Techn. Beratung
Mollardgasse 54
Vienna VI, Austria

BELGIUM

C. N. Rood S/A
30 Rue Leon Frederic
Brussels 4, Belgium

DENMARK

Tage Olsen A/S
Ronnegade 1-0
Copenhagen, Denmark

FINLAND

Oy Findip AB Ltd.
Mannerheimintie 29C
Helsinki 25, Finland

FRANCE

S. E. R. I. E. L., s. a.
48 Avenue Victor Hugo
Clamart (Seine) France

HONG KONG and MACAO

Intronics Ltd.
4 Hankow Road, Suite 4A
Kowloon, Hong Kong

ISRAEL

R. D. T. Electronics
Engineering Ltd.
P.O. Box 21082
13 Dov-Hos Street
Tel-Aviv, Israel

ITALY

Elettronucleonica s. p. a.
7 Pizza DeAngli
20146 Milano, Italy

JAPAN

Toyo Trading Co., Ltd.
Central P.O. Box 999
Tokyo, Japan

Toyo Trading Co., Ltd.
4-37, Minamihonmachi
Higashika, Osaka, Japan

KOREA

M. - C International
Room 516, Bando Building
Seoul, Korea

THE NETHERLANDS

C. N. Rood N. V.
Post Office Box 4542
Rijswijk (Z. H.) The Netherlands

Fluke Nederland N. V.
Post Office Box 5053
Tilburg, The Netherlands

NEW ZEALAND

Sample Electronics (N. Z.) Ltd.
8 Matipo Street
Onehunga
Auckland, New Zealand

NORWAY

Morgenstierne & Co. A/S
Wesselsgt. 6
Oslo, Norway

OKINAWA

RYUKYU ISLANDS

Baxter Trading Co.
P.O. Box 26
Koza, Okinawa
Ryukyu Islands

PHILIPPINES

T. J. Wolff
2246 Pasong Tamo
Makati, Rizal
Manila, Philippines

SOUTH AFRICA

A. C. Gowlett (Pty.) Ltd.
P.O. Box 1257
Johannesburg, So. Africa

A. C. Gowlett (Pty.) Ltd.
P.O. Box 3641
Cape Town, So. Africa

A. C. Gowlett (Pty.) Ltd.
P.O. Box 2143
Durban, Natal, So. Africa

SOUTH VIETNAM

R. B. Landis & Co., Inc.
216 Hien-Vuong
P.O. Box H-3
Saigon, Vietnam

SPAIN

REMA
Calle General Sanjurjo, 18
Madrid, Spain

SWEDEN

Robert E. O. Olsson
Box 165
Tradgardsgatan 7
Motala, Sweden

SWITZERLAND

Omni Ray AG
Dufourstrasse 56
8008 Zurich, Switzerland

TAIWAN

Heighten Scientific Co., Ltd.
P.O. 1408
Taipei, Taiwan

THAILAND

G. Simon Radio Ltd.
30 Patpong Avenue
Suriwong
Bangkok, Thailand

THE UNITED KINGDOM

Fluke International Corp.
P.O. Box 102
Watford-Herts, England

WEST GERMANY

Rohde & Schwarz Vertriebs - Gmbh
5000 Koeln
Hohe Strasse 160-168
West Germany

Rohde & Schwarz Handels - Gmbh
1000 Berlin 10
Ernst - Reuter - Platz 10
West Germany

Rohde & Schwarz Vertriebs - Gmbh
2000 Hamburg 50
Grosse Bergstrasse 213-217
West Germany

Rohde & Schwarz Vertriebs - Gmbh
7500 Karlsruhe
Kriegsstrasse 39
West Germany

Rohde & Schwarz Vertriebs - Gmbh
8000 Muenchen
Dachauer Strasse 109
West Germany

In Europe contact FLUKE NEDERLAND, N. V., Post Office Box 5053, Tilburg, The Netherlands

FLUKE

List of Factory Authorized Service Centers

ARIZONA

PHOENIX

Arizona Standards Laboratory
4430 N. 19th Ave
Tel. (602) 264-9351

CALIFORNIA

LOS ANGELES

Instrument Specialists, Inc.
P. O. Box 39908
2870 Los Feliz Place
Tel. (213) 665-5181
TWX: 910-321-3914

COLORADO

BOULDER

Ball Brothers Research Corp.
Standardization Laboratory
Tel. (303) 444-5300
TWX: 910-940-3241

FLORIDA

ORLANDO

BCS Associates, Inc.
P. O. Box 6578
940 N. Fern Creek Ave.
Tel. (305) 425-2764
TWX. 810-850-0185

HAWAII

HONOLULU

Industrial Electronics
P. O. Box 135
646 Queen Street
Tel. (808) 506-095
TWX. 63238

MARYLAND

KENSINGTON

Electronic Marketing Associates
11501 Huff Court
Tel. (301) 946-0300
TWX. 710-825-9645

MASSACHUSETTS

ARLINGTON

Instrument Representatives, Inc.
1046 Massachusetts Ave.
Tel. (617) 646-1034

MICHIGAN

CLAWSON

Electro Instrument Repair
1024 W. 14 Mile Road
Tel. (313) 588-6688

NEW MEXICO

ALBUQUERQUE

EG & G Standards & Calibration
Laboratory
P. O. Box 8346
608 East Sunset Road
Tel. (505) 265-8481

NEW YORK

PLEASANTVILLE

SBM Associates
28 Hobby Street
Tel. (914) 769-1811
TWX. 710-572-2193

ROCHESTER

SBM Associates
800 Linden Ave.
Tel. (716) 381-8330
TWX. 510-253-6145

PENNSYLVANIA

PHILADELPHIA

Acromatix Associates, Inc.
3118 Germantown Pike
Fairview Village, Penn.
Tel. (215) 279-0377

TEXAS

GARLAND

Tucker Electronics Company
326 Kirby Street
Tel. (214) 272-3404

HUSTON

Linear Standards Laboratory
8207 Millet
Tel. (713) 923-2796

UTAH

SALT LAKE CITY

Stabro Laboratory
23 Kensington Ave.
Tel. (801) 467-8011

CANADA

TORONTO

Allen Crawford Associates Ltd
65 Martin Ross Ave.
Downsview, Ontario
Tel. (416) 636-4910
TWX. 610-492-2119

INTERNATIONAL

THE NETHERLANDS

Fluke Netherland N.V.
P.O. Box 5053
Tilburg, The Netherlands

UNITED KINGDOM

Fluke International Corp.
P.O. Box 102
Watford-Herts, England

For information regarding service centers in other foreign locations, contact the nearest Sales and Service Representative in your area.


8038 & 803B/AG SERIAL 123 to 5802
803BR & 803BR/AG SERIAL 123 to 1150
CR101
CR102
CR103
680-730V
680 VAC
R109 270K
R110 270K
C101 2.0
C102 2.0
FOR 115V OPERATION, FUSE WITH 1.5A CONNECT 'N' TO 'G' & 'P' TO 'R'.
FOR 230V OPERATION, FUSE WITH .75A CONNECT 'G' TO 'P'.
POWER
ZERO
DECIMAL LAMPS
B+ SUPPLY
ZENER DIODE MODELS 803B/AG & 803BR/AG
STANDARD CELL MODELS 8038 & 803BR
FOR 8038 & 8038/AG SER 123 TO 731
8038R & 8038R/AG SER 123 TO 306
R503 WAS 5k
R538 WAS SELECTED
R541 WAS 1k
R542 WAS BRIDGED FOR A MINIMUM OF 48.5K
FOR #038 & 8038 AG SER 1562 TO ON
803BR & 803BR AG SER 532 TO ON
R6 & R7 WERE ADDED
FOR #038 & 8038 AG SER 123 TO 1771
803BR & 803BR AG SER 123 TO 531
C107 WAS CONNECTED FROM COLLECTOR OF Q1 TO REFERENCE SUPPLY COMMON
FOR #038 & 8038 AG SER 123 TO 2530
803BR & 803BR AG SER 123 TO 776
Q1 WAS A 2N214
R104 WAS 5k
R105 WAS 1.35K
FOR #038 & 8038 AG SER 123 TO 2616
803BR & 803BR AG SER 123 TO 851
C213 WAS 3.3PF
R221 WAS 2.2k
FOR #038 & 8038/AG SER 2617 TO 3025
803BR & 803BR/AG SER 852 TO 881
C211 WAS 0.1B
FOR #038 & 8038/AG SER 123 TO 3025
803BR & 803BR/AG SER 123 TO 88
R216 WAS 560
R218 WAS 93.1
FOR #038 & 8038 AG SER 123 TO 3566
803BR & 803BR AG SER 123 TO 976
C503 WAS .1B
FOR 8038 SER 123 TO 3504
803BR SER 123 TO 1022
R316 & R317 WERE 125k
R319 WAS 511.7
& R317 WERE 125k
WAS 2k
AG SER 123 TO 3944
BR AG SER 123 TO 1091
WAS CONNECTED TO TERMINAL A INSTEAD OF TERMINAL BB
& AG SER 123 TO 3693
AG 123 TO 1104
R5 3 2k
AG SER 2616 TO 3693
AG SER 851 TO 1104
2 2k
8038 & 803B/AG SERIAL 5803 & ON
803BR & 803BR/AG SERIAL 1151 & ON
8038/AF 6160 & ON
680 VAC
495V
500V
50V
5V
.5V
DECIMAL LAMPS
B+ SUPPLY
Q1 2N3721
Q2 2N3721
Q3
Q4 2N3721
Q5
Q6
Q7
Q8
V104
4.5
R108 50
R107 50
R106 820
R105 115K
R104 6.49K
C107 .01
C105 .05
R103 2.49K
R102 2.49K
R101 2.49K
R100 2.49K
R99 2.49K
R98 2.49K
R97 2.49K
R96 2.49K
R95 2.49K
R94 2.49K
R93 2.49K
R92 2.49K
R91 2.49K
R90 2.49K
R89 2.49K
R88 2.49K
R87 2.49K
R86 2.49K
R85 2.49K
R84 2.49K
R83 2.49K
R82 2.49K
R81 2.49K
R80 2.49K
R79 2.49K
R78 2.49K
R77 2.49K
R76 2.49K
R75 2.49K
R74 2.49K
R73 2.49K
R72 2.49K
R71 2.49K
R70 2.49K
R69 2.49K
R68 2.49K
R67 2.49K
R66 2.49K
R65 2.49K
R64 2.49K
R63 2.49K
R62 2.49K
R61 2.49K
R60 2.49K
R59 2.49K
R58 2.49K
R57 2.49K
R56 2.49K
R55 2.49K
R54 2.49K
R53 2.49K
R52 2.49K
R51 2.49K
R50 2.49K
R49 2.49K
R48 2.49K
R47 2.49K
R46 2.49K
R45 2.49K
R44 2.49K
R43 2.49K
R42 2.49K
R41 2.49K
R40 2.49K
R39 2.49K
R38 2.49K
R37 2.49K
R36 2.49K
R35 2.49K
R34 2.49K
R33 2.49K
R32 2.49K
R31 2.49K
R30 2.49K
R29 2.49K
R28 2.49K
R27 2.49K
R26 2.49K
R25 2.49K
R24 2.49K
R23 2.49K
R22 2.49K
R21 2.49K
R20 2.49K
R19 2.49K
R18 2.49K
R17 2.49K
R16 2.49K
R15 2.49K
R14 2.49K
R13 2.49K
R12 2.49K
R11 2.49K
R10 2.49K
R9 2.49K
R8 2.49K
R7 2.49K
R6 2.49K
R5 2.49K
R4 2.49K
R3 2.49K
R2 2.49K
R1 2.49K



NOTES

1. All voltage measurements shown are taken under the following conditions:
   (a) RANGE switch set to 500.
   (b) NULL switch set to VTVM.
   (c) All voltage readout dials set to zero.
   (d) AC-DC polarity switch set to +.
   (e) Line voltage at 115/230 volts, 50-60 cycles.
   (f) All measurements made with a VTVM (10 megohms input resistance) to the negative binding post.
2. All voltages are DC unless otherwise indicated.
3. $\perp_1$ Indicates null detector common.
4. $\perp_2$ Indicates reference supply and converter common.
5. $\perp_1$ and $\perp_2$ may differ in voltage by amount indicated on voltage readout dials.
6. ▷ All flagnotes with the same number are connected.
7. ⊖ Indicates internal adjustment.
8. Unless otherwise indicated, resistances are in ohms and capacitances are in microfarads.
9. On some Null Detector Printed Circuit Boards, C215, CR202, and CR203 have been designated as C2, CR1, and CR2.
10. NE2E FROM S/N 123 THRU 4115 IN 803B AND 803 P/AG. NE2E FROM S/N 123 THRU 1142 IN 803 BR AND 803 B/AG.

FUNCTIONAL SCHEMATIC

DIFFERENTIAL VOLTMETER

MODEL 803B, 803BR, 803B/AG, & 803BR/AG

803B & 803B/AG SER. NO. 123 & ON
803BR & 803BR/AG SER. NO. 123 & ON

FLUKE JOHN FLUKE MFG. CO. INC.
P.O. Box 7421 Seattle, Washington 98133

11 AUGUST 1967